

## MaxiSys MS909EV



**USER MANUA** 

## Patent

This product is protected by patents in the U.S. and elsewhere. For more information, please visit https://autel.us/virtual-patents/.

## Trademarks

Autel<sup>®</sup>. MaxiSvs<sup>®</sup>. MaxiDAS<sup>®</sup>. MaxiScan<sup>®</sup>. MaxiTPMS<sup>®</sup>. MaxiRecorder<sup>®</sup>. and MaxiCheck® are trademarks of Autel Intelligent Technology Corp., Ltd., registered in China, the United States, and other countries. All other marks are trademarks or registered trademarks of their respective holders.

## Copyright Information

No part of this manual may be reproduced, stored in a retrieval system or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise without the prior written permission of Autel.

## Disclaimer of Warranties and Limitation of Liabilities

All information, specifications and illustrations in this manual are based on the latest information available at the time of printing.

Autel reserves the right to make changes at any time without notice. While information of this manual has been carefully checked for accuracy, no guarantee is given for the completeness and correctness of the contents, including but not limited to the product specifications, functions, and illustrations.

Autel will not be liable for any direct, special, incidental, or indirect damages, or for any economic consequential damages (including the loss of profits) as a result of using this product.

#### 

Before operating or maintaining this unit, please read this manual carefully, paying extra attention to the safety warnings and precautions.

## For Services and Support



(P) pro.autel.com www.autel.com

1-855-288-3587 (North America) +86 (0755) 8614-7779 (China)

support@autel.com

i

For technical assistance in all other markets, please refer to *Technical Support* in this manual.

## **Safety Information**

For your own safety and the safety of others, and to prevent damage to the device and vehicles upon which it is used, it is important that the safety instructions presented throughout this manual be read and understood by all persons operating or coming into contact with the device.

There are numerous procedures, techniques, tools, and parts required for servicing vehicles, as well as the skills of the person doing the work. Because of the vast number of test applications and variations in the products that can be tested with this equipment, we cannot possibly anticipate or provide advice or safety messages to cover every circumstance. It is the automotive technician's responsibility to be knowledgeable of the system being tested. It is crucial to use proper service methods and test procedures. It is essential to perform tests in an appropriate and acceptable manner that does not endanger your safety, the safety of others in the work area, the device being used, or the vehicle being tested.

Before using the device, always refer to and follow the safety messages and applicable test procedures provided by the manufacturer of the vehicle or equipment being tested. Use the device only as described in this manual. Be sure to read, understand, and follow all safety messages and instructions in this manual.

## **Safety Messages**

Safety messages are provided to help prevent personal injury and equipment damage. All safety messages are introduced by a signal word indicating the hazard level.

#### 

Indicates an imminently hazardous situation which, if not avoided, could result in death or serious injury to the operator or to bystanders.

## 

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to the operator or to bystanders.

## **Safety Instructions**

The safety messages herein cover situations Autel is aware of at the time of publication. Autel cannot know, evaluate or advise you as to all of the possible hazards. You must be certain that any condition or service procedure encountered does not jeopardize your personal safety.

## 

When an engine is operating, keep the service area WELL VENTILATED or attach a building exhaust removal system to the engine exhaust system. Engines produce carbon monoxide, an odorless, poisonous gas that causes slower reaction time and can lead to serious personal injury or loss of life.

#### M It is not advised to use headphones at a high volume

Listening at high volumes for long periods of time may result in loss of hearing.

#### A Safety Warnings

- Always perform automotive testing in a safe environment.
- Wear safety eye protection that meets ANSI standards.
- Keep clothing, hair, hands, tools, test equipment, etc. away from all moving or hot • engine parts.
- Operate the vehicle in a well-ventilated work area, for exhaust gases are poisonous. •
- Put the transmission in PARK (for automatic transmission) or NEUTRAL (for manual transmission) and make sure the parking brake is engaged.
- Put blocks in front of the drive wheels and never leave the vehicle unattended while testing.
- Be extra cautious when working around the ignition coil, distributor cap, ignition wires and spark plugs. These components create hazardous voltages when the engine is running.
- Keep a fire extinguisher suitable for gasoline, chemical, and electrical fires nearby. •
- Do not connect or disconnect any test equipment while the ignition is on or the • engine is running.
- Keep the test equipment dry, clean, free from oil, water or grease. Use a mild detergent on a clean cloth to clean the outside of the equipment as necessary.
- Do not drive the vehicle and operate the test equipment at the same time. Any distraction may cause an accident.
- Refer to the service manual for the vehicle being serviced and adhere to all diagnostic procedures and precautions. Failure to do so may result in personal injury or damage to the test equipment.
- To avoid damaging the test equipment or generating false data, make sure the vehicle battery is fully charged and the connection to the vehicle DLC is clean and secure.
- Do not place the test equipment on the distributor of the vehicle. Strong electromagnetic interference can damage the equipment.

## CONTENTS

1	USING	THIS MANUAL	1
	1.1 Co	DNVENTIONS	1
	1.1.1	Bold Text	1
	1.1.2	Notes and Important Messages	1
	1.1.3	Hyperlink	1
	1.1.4	Illustrations	1
	1.1.5	Procedures	2
2	GENER	AL INTRODUCTION	3
	2.1 M/	AXISYS TABLET	3
	2.1.1	Function Description	3
	2.1.2	Power Sources	5
	2.1.3	Technical Specifications	6
	2.2 M/	axiFlash VCI	7
	2.2.1	Function Description	7
	2.2.2	Power Sources	8
	2.2.3	Technical Specifications	9
	2.3 E\	/DIAG BOX	10
	2.3.1	Function Description	10
	2.3.2	Power Source	11
	2.3.3	Technical Specifications	11
	2.4 Ac	CCESSORIES KIT	12
	2.4.1	Main Cable	12
	2.4.2	Battery Pack Accessories	12
	2.4.3	OBDI-Type Adapters (Optional)	14

	2.5	Отн	IER ACCESSORIES	.14
3	GET	TING	G STARTED	.16
	3.1	Pov	NER UP	.16
	3.1	.1	Application Buttons	.17
	3.1	.2	Locator and Navigation Buttons	.19
	3.1	.3	System Status Icons	.20
	3.2	Pov	NER DOWN	.20
	3.2	.1	Reboot System	.21
4	NEV	V EN	ERGY	.22
	4.1	Est	ABLISH VEHICLE COMMUNICATION AND SELECTION	.22
	4.1	.1	Establish Vehicle Communication	.22
	4.2	Get	ITING STARTED	.27
	4.2	.1	Vehicle Menu Layout	.27
	4.3	Veh	ICLE IDENTIFICATION	.29
	4.3	.1	Auto Detect	.29
	4.3	.2	Manual Input	.30
	4.3	.3	Scan VIN/License	.30
	4.3	.4	Manual Vehicle Selection	.31
	4.4	ΝΑ	/IGATION	.32
	4.4	.1	New Energy Screen Layout	.32
	4.4	.2	Screen Messages	.35
	4.5	DIA	GNOSTICS MENU	.35
	4.6	Dia	GNOSTICS FUNCTIONS	.36
	4.6	.1	ECU Information	.41
	4.6	.2	Trouble Codes	.41
	4.6	.3	Live Data	.43

4.6	6.4 Active Test	50
4.6	6.5 Special Functions	50
4.7	HV SYSTEM DIAGNOSTICS	50
4.7	7.1 System List > SME (Storage Management Electronics)	53
4.7	7.2 System Block Diagram	57
4.8	Programming and Coding	61
4.8	8.1 Coding	62
4.8	8.2 Reprogramming	62
4.8	8.3 Re-flash Errors	63
4.9	DIAGNOSTIC REPORT	63
4.9	9.1 Pre-Scan and Post-Scan Functions	63
4.9	9.2 Diagnostics Report Saving, Viewing, and Sharing	64
4.10	EXIT NEW ENERGY APPLICATION	68
5 BA	TTERY PACK TEST	70
<b>5 BA</b> T 5.1	TTERY PACK TEST	
		70
5.1 5.2	GETTING STARTED	70
5.1 5.2 5.2	Getting Started	70 75 75
5.1 5.2 5.2	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information	70 75 75 <b>76</b>
5.1 5.2 5.2 <b>6 DIA</b>	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information AGNOSTICS GENERIC OBDII OPERATIONS	70 75 75 <b>76</b> 
5.1 5.2 6 DIA 6.1 6.1	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information AGNOSTICS GENERIC OBDII OPERATIONS	70 75 75 <b>76</b> 76 
5.1 5.2 6 DIA 6.1 6.1 6.1	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information AGNOSTICS GENERIC OBDII OPERATIONS 1.1 General Procedure	70 75 75 
5.1 5.2 6 DIA 6.1 6.1 6.1	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information AGNOSTICS GENERIC OBDII OPERATIONS 1.1 General Procedure 1.2 Function Descriptions	70 75 75 76 76 76 
5.1 5.2 6 DIA 6.1 6.1 6.1 7 SEF	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information AGNOSTICS GENERIC OBDII OPERATIONS 1.1 General Procedure 1.2 Function Descriptions RVICE	70 75 75 76 76 76 76 77 
5.1 5.2 6 DIA 6.1 6.1 7 SEF 7.1 7.2	GETTING STARTED VEHICLE MODE 2.1 Battery Pack Information AGNOSTICS GENERIC OBDII OPERATIONS 1.1 General Procedure 1.2 Function Descriptions RVICE OIL RESET SERVICE	

	7.4	BATTERY MANAGEMENT SYSTEM (BMS) SERVICE		
	7.5	DIESEL PARTICLE FILTER (DPF) SERVICE		
	7.6	IMMOBILIZER (IMMO) SERVICE		
	7.7	STEERING ANGLE SENSOR (SAS) SERVICE		
8	ADA	S86		
9	DAT	A MANAGER87		
	9.1	VEHICLE HISTORY		
	9.1.	1 Historical Test Record90		
	9.2	WORKSHOP INFORMATION		
	9.3	CUSTOMER91		
	9.4	IMAGE		
	9.5	CLOUD REPORT		
	9.6	PDF FILES94		
	9.7	REVIEW DATA94		
	9.8	DATA LOGGING		
	9.9	UNINSTALL APPS95		
1(	0 BAT	TERY TEST96		
	10.1	MAXIBAS BT506 BATTERY TESTER97		
	10.1	1.1 Function Description97		
	10.1	1.2 Power Sources		
	10.1	1.3 Technical Specifications		
	10.2	Test Preparation		
	10.2	2.1 Inspect the Battery99		
	10.2	2.2 Connect the Battery Tester		
	10.3	IN-VEHICLE TEST		
	10.3	3.1 Battery Test		

10.3.2	2 Starter Test104
10.3.3	Generator Test105
10.4	OUT-VEHICLE TEST
10.4.1	Test Procedure106
10.4.2	2 Test Results107
-	ТЕ108
12 SETTI	NGS109
12.1	UNIT
12.2	Language
12.3	PRINT SETTINGS
12.3.1	Printing Operations110
12.4	REPORT SETTINGS
12.5	PUSH NOTIFICATION
12.6	AUTO UPDATE
12.7	ADAS SETTINGS
12.8	VEHICLE LIST
12.9	EVDIAG BOX SETTINGS
12.10	AUTOVID SETUP
12.11	COUNTRY/REGION CODE
12.12	SYSTEM SETTINGS
12.13	Авоит
13 VCI M	ANAGER
13.1	WI-FI CONNECTION
13.2	VCI BLUETOOTH PAIRING116
13.3	BAS BLUETOOTH PAIRING
13.4	VCI UPDATE118

13.5	BAS UPDATE	118	
14 SUPPO	DRT	119	
14.1	SUPPORT SCREEN LAYOUT	119	
14.2	MY ACCOUNT	119	
14.2.1	Personal Information	120	
14.2.2	Update Information	120	
14.2.3	Service Information	120	
14.3	TRAINING	120	
14.4	DATA LOGGING	120	
14.5	FAQ	121	
15 MAXIV	IEWER	122	
16 MAXIV	IDEO	125	
17 QUICK	LINK	126	
18 REMO	TE DESKTOP	127	
18.1	OPERATIONS	127	
19 USER	FEEDBACK	129	
20 AUTEL	USER CENTER	130	
21 MAINT	ENANCE AND SERVICE	132	
21.1	MAINTENANCE INSTRUCTIONS	132	
21.2	TROUBLESHOOTING CHECKLIST	133	
21.3	About Battery Usage	133	
21.4	Service Procedures	134	
21.4.1	Technical Support	134	
21.4.2	Repair Service	136	
21.4.3	Other Services	137	
22 COMP	22 COMPLIANCE INFORMATION138		
23 WARR	ANTY	140	

# **1** Using This Manual

This manual contains device usage instructions.

Some illustrations shown in this manual may contain modules and optional equipment that are not included in your system.

## 1.1 Conventions

The following conventions are used:

## 1.1.1 Bold Text

Bold text is used to highlight selectable items such as buttons and menu options.

Example:

• Tap **OK**.

## 1.1.2 Notes and Important Messages

1.1.2.1 Notes

A **NOTE** provides helpful information such as additional explanations, tips, and comments.

1.1.2.2 Important

**IMPORTANT** indicates a situation that if not avoided may result in damage to the tablet or vehicle.

## 1.1.3 Hyperlink

Hyperlinks are available in electronic documents. Blue italic text indicates a selectable hyperlink; blue underlined text indicates a website link or an email address link.

## 1.1.4 Illustrations

Illustrations used in this manual are samples, the actual testing screen may vary for each vehicle being tested. Observe the menu titles and on-screen instructions to make correct

option selection.

## 1.1.5 Procedures

An arrow icon indicates a procedure. Example:

#### > To power down the MaxiSys tablet

- 1. Long press (press and hold) the **Power/Lock** button.
- 2. Tap the **Power Off** option.
- 3. Tap **OK**.

## **2** General Introduction

There are three main components to the MaxiSys system:

- MaxiSys Tablet the central processor and monitor for the system.
- MaxiFlash VCI the vehicle communication interface.
- EVDiag Box the battery pack communication interface.

This manual describes the construction and operation of these devices and how they work together to deliver diagnostic solutions.

## 2.1 MaxiSys Tablet

## 2.1.1 Function Description



Figure 2-1 MaxiSys Tablet Front View

- 1. 9.7" TFT-LCD Capacitive Touchscreen
- 2. Ambient Light Sensor detects ambient light brightness
- 3. Power LED refer to Table 2-1 Power LED Description for details
- 4. Front Camera
- 5. Built-in Microphone

#### Table 2-1 Power LED Description

LED Color Description		Description
	Green	• Lights solid green when the tablet is charging and the battery level is greater than or equal to 90%.
Power		<ul> <li>Lights solid green when the tablet is powered on and the battery level is greater than or equal to 15%.</li> </ul>
Fower	Yellow	Lights solid yellow when the tablet is charging and the battery level is below 90%.
	Red	Lights solid red when the tablet is powered on and the battery level is below 15%.



Figure 2-2 MaxiSys Tablet Back View

- 6. Speaker
- 7. Collapsible Stand extends from the back to allow hands-free viewing of the tablet
- 8. Rear Camera
- 9. Camera Flash



Figure 2-3 MaxiSys Tablet Top View

- 10. Headphone Jack
- 11. USB Port
- 12. USB Port
- 13. Mini USB Port
- 14. HDMI (High-Definition Multimedia Interface) Port
- 15. Micro SD Card Slot
- 16. DC Power Supply Input Port
- 17. Power/Lock Button long press to turn on/off the tablet; short press to lock the screen

## 2.1.2 Power Sources

The tablet can receive power from any of the following sources:

- Internal Battery Pack
- AC/DC Power Supply
- Vehicle Power

#### IMPORTANT

Do not charge the battery when the temperature is lower than 0  $^\circ C$  (32  $^\circ F)$  or higher than 45  $^\circ C$  (113  $^\circ F).$ 

#### 2.1.2.1 Internal Battery Pack

The tablet can be powered with the internal rechargeable battery, which if fully charged can provide sufficient power for about 8 hours of continuous operation.

#### 2.1.2.2 AC/DC Power Supply

The tablet can be powered from an electrical outlet using the AC/DC power adapter. The AC/DC power supply also charges the internal battery pack.

#### 2.1.2.3 Vehicle Power

The tablet can be powered from the auxiliary power outlet adapter or other DC power port on the test vehicle through a direct cable connection. The vehicle power cable connects to the DC power supply port on the top side of the tablet.

## 2.1.3 Technical Specifications

Item	Description
Operating System	Android 10
Processor	Octa-core processor (4 x 2.2 GHz; 4 x 1.8 GHz)
Memory	4 GB RAM & 128 GB on-board memory
Display	9.7-inch TFT-LCD with 1536 x 2048 resolution & capacitive touchscreen
Connectivity	<ul> <li>Wi-Fi x 2 (802.11 a/b/g/n/ac 2x2 MIMO)</li> <li>BT V5.0 + BR/EDR</li> <li>GPS</li> <li>USB 2.0 (two USB host type A, one USB mini device)</li> <li>HDMI 2.0</li> <li>SD card (supports up to 256 GB)</li> </ul>
Camera	<ul> <li>Rear: 16 Megapixel, autofocus with flashlight</li> <li>Front: 16 Megapixel</li> </ul>
Sensors	<ul> <li>Gravity accelerometer</li> <li>Ambient Light Sensor (ALS)</li> </ul>
Audio Input / Output	<ul> <li>Microphone</li> <li>Dual speakers</li> <li>3-band 3.5 mm stereo/standard headset jack</li> </ul>
Power and Battery	<ul> <li>15000 mAh 3.8 V lithium-polymer battery</li> <li>Charging via 12 V AC/DC power supply with the temperature between 0 °C (32 °F) and 45 °C (113 °F)</li> </ul>
Input Voltage	12 V/3 A adapter

Item	Description
Operating Temp.	0 °C to 50 °C (32 °F to 122 °F)
Storage Temp.	-10 °C to 60 °C (14 °F to 140 °F)
Dimensions (W x H x D)	304.4 mm (11.98") x 227.8 mm (8.97") x 42.5 mm (1.67")
Weight	1.66 kg (3.66 lbs.)
Protocols	PLC J2497, ISO-15765, SAE-J1939, ISO-14229 UDS, SAE- J2411 Single Wire Can(GMLAN), ISO-11898-2, ISO-11898-3, SAE-J2819 (TP20), TP16, ISO-9141, ISO-14230, SAE-J2610 (Chrysler SCI), UART Echo Byte, SAE-J2809 (Honda Diag- H), SAE-J2740 (GM ALDL), SAE-J1567 (CCD BUS), Ford UBP, Nissan DDL UART with Clock, BMW DS2, BMW DS1, SAE J2819 (VAG KW81), KW82, SAE J1708, SAE-J1850 PWM (Ford SCP), SAE-J1850 VPW (GM Class2), ISO 13400, CAN FD

## 2.2 MaxiFlash VCI

## 2.2.1 Function Description



Figure 2-4 MaxiFlash VCI Programming Device

- 1. DC Power Supply Input Port
- 2. Vehicle Data Connector
- 3. Ethernet Port
- 4. Vehicle LED
  - Flashes green when the device is communicating with the vehicle system

- 5. Connection LED
  - Lights solid green when the device is properly connected with the tablet via the USB cable
  - Lights solid cyan (blue and green) when connected via Wi-Fi; lights solid blue when connected via Bluetooth connection
- 6. Power LED
  - Lights solid green when powered on
  - Flashes red when VCI is upgrading
  - Lights solid red when a system failure occurs
  - Lights yellow automatically at power up when VCI is self-testing
- 7. USB Port

#### IMPORTANT

Do not disconnect the programming device while the vehicle LED status light is on. If the flash programming procedure is interrupted while the vehicle's ECU is blank or only partially programmed, the module may be unrecoverable.

#### 2.2.1.1 Programming Capability

The MaxiFlash VCI device is a D-PDU, SAE J2534 & RP1210 compliant PassThru programming interface device. Using the updated OEM software, it is capable of replacing the existing software/firmware in the Electronic Control Units (ECU), programming new ECUs, and fixing software-controlled drivability issues and emission issues.

#### 2.2.1.2 Communication Capability

The MaxiFlash VCI device supports Bluetooth (BT), Wi-Fi, and USB communications. It can transmit vehicle data to the tablet with or without a cable connection. In open areas, the working range of the transmitter through Bluetooth communication is up to 328 feet (about 100 m). The working range of 5G Wi-Fi is up to 164 feet (50 m). If the signal is lost due to being taken out of range, once the tablet is within range again, the communication will be restored.

#### 2.2.2 Power Sources

The VCI device can receive power from the following sources:

- Vehicle Power
- AC/DC Power Supply

#### 2.2.2.1 Vehicle Power

The VCI device operates on 12/24 volts vehicle power, which receives power via the vehicle data connection port. The device powers on whenever it is connected to an OBDII/EOBD compliant Data Link Connector (DLC). For non-OBDII/EOBD compliant vehicles, the device can be powered from an auxiliary power outlet adapter or other suitable power port on the test vehicle using the auxiliary power cable.

#### 2.2.2.2 AC/DC Power Supply

The VCI device can be powered from a wall socket using the AC/DC power adapter.

## 2.2.3 Technical Specifications

Item	Description
Communications	<ul> <li>Bluetooth V2.1 + EDR</li> <li>USB 2.0</li> <li>Wi-Fi 5G</li> <li>Ethernet</li> </ul>
Wireless Frequency	5 GHz
Input Voltage Range	12 V DC to 24 V DC
Supply Current	<ul> <li>170 mA @12 V DC</li> <li>100 mA @ 24 V DC</li> </ul>
Operating Temp.	0 °C to 50 °C (32 °F to 122 °F)
Storage Temp.	-10 °C to 60 °C (14 °F to 140 °F)
Dimensions (W x H x D)	86 mm (3.38") x 149 mm (5.87") x 35 mm (1.28")
Weight	0.29 kg (0.64 lbs)

#### Table 2-3 MaxiFlash VCI Specifications

## 2.3 EVDiag Box

## 2.3.1 Function Description



Figure 2-5 EVDiag Box Top View

1. DB25 Connector



Figure 2-6 EVDiag Box Bottom View

- 2. DC Power Supply Input Port
- 3. OBDII Connector



Figure 2-7 EVDiag Box Front View

- 4. HV LED flashes yellow when the device is connected to the battery pack during high voltage output
- 5. ACC/ON LED lights green when the ACC/ON ignition signal output is normal
- 6. BAT + LED lights green when the power output is normal
- 7. Run LED lights blue when communicating with the tablet
- 8. Power LED refer to Table 2-4 Power LED Description for EVDiag Box for details

Table 2-4 Power LED Description for EVDiag Box

LED	Color	Description
	Green	Lights green when operating normally.
Power	Red	<ul><li>Flashes red when upgrading.</li><li>Lights red when upgrade has failed.</li></ul>

## 2.3.2 Power Source

The EVDiag Box can be powered from a wall socket using the 12 V DC adapter.

## 2.3.3 Technical Specifications

#### Table 2-5 EVDiag Box Specifications

Item	Description
Input Voltage	12 V DC
Max. Input Current	3 A
Operating Temp.	0 °C to 50 °C (32 °F to 122 °F)
Storage Temp.	-20 °C to 60 °C (-4 °F to 140 °F)
Dimensions (L x W x H)	166 mm (6.54") x 168.35 mm (6.63") x 47.35 mm (1.86")
Weight	0.648 kg (1.43 lbs.)

## 2.4.1 Main Cable

The VCI device can be powered through the Autel main cable V2.0 (the V2.0 icon can be seen on the cable) when connected to an OBDII/EOBD compliant vehicle. The main cable connects the VCI device to the vehicle's Data Link Connector (DLC), through which the VCI device can transmit vehicle data to the tablet.



Figure 2-8 Main Cable V2.0

#### **NOTE**

The MaxiFlash VCI can only be connected by the Autel main cable V2.0. DO NOT use other Autel main cables to connect the MaxiFlash VCI.

## 2.4.2 Battery Pack Accessories

Cables, adapters, breakout leads, breakout lead extension cords or dual banana plugs will be used to perform the HV pack test.

Item	Qty	Ref. Pic.
EVDiag Box Main Cable BPTC0001/01	1 pc	
Adapter BPTC0101/01	1 pc	
Adapter BPTC0102/01	1 pc	
Adapter BPTC0103/01	1 рс	

Table 2-6 Battery Pack Accessories List

Item	Qty	Ref. Pic.
Adapter BPTC0201/01	1 pc	je∎∕−€ ∖−∎−€
Adapter BPTC0202/01	1 pc	<b>D===</b>
Adapter BPTC0203/01	1 pc	
Adapter BPTC0204/01	1 pc	
Adapter BPTC0205/01	1 pc	
Adapter BPTC1101/01	1 pc	<b>D-</b> ( <b>1</b> )
Adapter BPTC1102/01	1 pc	
Breakout Lead 1	6 pcs	
Breakout Lead 2	6 pcs	
Breakout Lead 3	6 pcs	
Breakout Lead 4	6 pcs	
Breakout Lead Extension Cord	3 pcs	
DB25 Snake Cable BPTJ0001/01	1 рс	
Dual Banana Plug	4 pcs	

## 2.4.3 OBDI-Type Adapters (Optional)

The optional OBDI-type adapters are for non-OBDII vehicles. The adapter used depends on the type of vehicle being tested. The most common adapters are shown below. (Adapters are sold separately. Please contact your distributor for details.)



## 2.5 Other Accessories

USB 2.0 Cable V2 (the V2 icon can be seen on the cable) Connects the tablet to the VCI device.
<b>AC/DC Adapter (12 V)</b> Connects the tablet to the external AC/DC power port for power supply.

Auxiliary Power Outlet Adapter
Provides power to the tablet or the VCI device through connection to the vehicle's auxiliary power outlet adapter receptacle, as some non-OBDII vehicles cannot provide power via the DLC connection.
Clamp Cable Provides power to the tablet or the VCI device through connection to the vehicle's battery.
USB to Ethernet Adapter
Network connection function can be realized through this device.
Lighter Fuse x2
A safety device for the auxiliary power outlet adapter.

## **3** Getting Started

Make sure that the tablet has sufficient power or is connected to the external power supply (see *Power Sources*).

## 3.1 Power Up

Long press (press and hold) the **Power/Lock** button on the top-right side of the tablet to switch the unit on. Swipe up from the bottom of the Lock screen to enter the MaxiSys Job Menu screen.



Figure 3-1 MaxiSys Job Menu

- 1. Application Buttons
- 2. Locator and Navigation Buttons
- 3. Status Icons

#### 🖉 NOTE

It is recommended that you lock the screen when not in use to protect information in the system and conserve the power.

Almost all operations on the tablet are controlled through the touchscreen. The touchscreen navigation is menu-driven, allowing for quick access to the test procedure or the data that you need, through a series of questions and options. Detailed

descriptions of the menu structures are found in the chapters for each application.

## 3.1.1 Application Buttons

The table below briefly describes each of the applications in the MaxiSys system.

Button	Name	Description
	New Energy	Accesses the diagnostics function for new energy vehicles. See <i>New Energy</i> .
( uning)	Battery Pack Test	Accesses the high-voltage battery pack test function. See <i>Battery Pack Test</i> .
	Diagnostics	Accesses the diagnostics functions. See <i>Diagnostics</i> .
F.	Service	Accesses special functions menu. See Service.
ADAS	ADAS	Accesses ADAS systems menu. See ADAS.
<b>E</b>	Data Manager	Accesses the saved repair shop, customer and vehicle data including detailed vehicle diagnostics and test records. See <i>Data Manager</i> .
 5©	Battery Test	Accesses the Battery Test menu with two functions, including in-vehicle test and out-vehicle test. See <i>Battery Test</i> .
J	Update	Accesses system software update menu. See Update.

#### Table 3-1 Applications

Button	Name	Description
<b>@</b>	Settings	Accesses the system settings menu and general tablet menu. See <i>Settings</i> .
vcı	VCI Manager	Accesses VCI connection menu. See VCI Manager.
*	Support	Synchronizes Autel's online service database with the MaxiSys tablet. See <i>Support</i> .
	OEM Authorization	Manages the permissions for unlocking the OE gateway.
FQ	MaxiViewer	Provides a quick search for supported functions and/or vehicles. See <i>MaxiViewer</i> .
Ó	MaxiVideo	Configures the unit to operate as a video scope device by connecting to an imager head cable for close vehicle inspections. See <i>MaxiVideo</i> .
	Quick Link	Provides associated website bookmarks to allow quick access to product update, service, support, and other information. See <i>Quick Link</i> .
	Remote Desktop	Configures your tablet to receive remote support using the TeamViewer application. See <i>Remote Desktop</i> .
2	User Feedback	You can submit feedback through this application when you encounter problems during the use of the tablet. See <i>User Feedback</i> .
2	Autel User Center	Allows users to register Autel tool for downloading the latest released software. See <i>Autel User Center</i> .

## 3.1.2 Locator and Navigation Buttons

Operations of the Navigation buttons at the bottom of the screen are described in the table below:

Icon	Name	Description
	Locator	Indicates the location of the screen. Swipe the screen left or right to view the previous or next screen.
•	Back	Returns to the previous screen.
	MaxiSys Home	Returns to MaxiSys Job Menu.
	Android Home	Returns to Android system home screen.
	Recent Apps	Displays a list of applications that are currently running. Tap an app icon to launch. Close a running application by swiping it to the top. Or close all running applications by tapping <b>Clear All</b> .
9	Browser	Launches the Chrome Internet browser.
Ô	Camera	Tap the <b>Camera</b> icon to open camera viewfinder. Press and hold the icon to capture a screenshot of the display screen. The saved files are auto-stored in the Data Manager application for later review. See <i>Data Manager</i> .
*	Display & Sound	Adjusts the brightness of the screen and the volume of the audio output.
VCL VCL VCL	VCI Shortcut	Opens the VCI Manager application. A green icon at the bottom-right corner indicates the VCI device is connected, while a red "X" icon will be displayed if the connection fails.
	MaxiSys Shortcut	Returns to the Diagnostics screen.

Table 3-2 Locator and Navigation Buttons

Icon	Name	Description
Ē	Service Shortcut	Returns to the Service screen.

#### > To use the camera

- 1. Tap the Camera icon. The camera screen opens.
- 2. Focus the image to be captured in the viewfinder.
- 3. Tap the **camera** icon on the right side of the screen. The viewfinder now shows the captured picture and auto-saves the taken photo.
- 4. Tap the thumbnail image on the top-right corner of the screen to view the stored images.
- 5. Tap the **Back** or **Home** button to exit the camera application.

#### 🖉 ΝΟΤΕ

After swiping the camera screen from left to right, the camera mode and video mode can be switched by tapping the **Camera** icon or **Video** icon.

### 3.1.3 System Status Icons

Your MaxiSys tablet is a fully functional Android tablet with the standard Android operating system status icons. Refer to Android documentation for additional information.

## 3.2 Power Down

All vehicle communications should be terminated before shutting down the tablet. A warning message displays if a shutdown is attempted while the tablet is communicating with the vehicle. Forcing a shutdown while the tablet is communicating with the vehicle may lead to ECU errors on some vehicles. Please exit the Diagnostics application before shutting off the tablet.

#### > To power down the MaxiSys tablet

- 1. Long press (press and hold) the **Power/Lock** button.
- 2. Tap the **Power Off** option.
- 3. Tap **OK**.

## 3.2.1 Reboot System

In case of a system crash, long press the **Power/Lock** button and tap **Restart** to reboot the system.

## 4 New Energy

The MaxiSys MS909EV can perform comprehensive diagnostics on new energy vehicles. After establishing communication with the ECU on a new energy vehicle through the VCI device, the tablet is able to read or clear DTCs, read live data, perform active test, programming, and more. The tablet can perform diagnostics on high voltage systems of new energy vehicles through communication with their electronic control systems.

## 4.1 Establish Vehicle Communication and Selection

## 4.1.1 Establish Vehicle Communication

The Diagnostics operations require connecting the MaxiSys tablet to the test vehicle through the VCI device using the main cable. (Use the applicable OBD I-type adapter if needed.) To establish a proper vehicle communication with the tablet, you need to perform the following steps:

- 1. Connect the VCI device to the vehicle's DLC for both communication and power supply.
- 2. Connect the VCI device to the tablet via Bluetooth pairing, Wi-Fi, or USB connection.
- 3. When the above steps are completed, check the VCI Manager Shortcut at the bottom of the screen. If a green BT, Wi-Fi, or USB icon displays at the lower-right corner, the MaxiSys tablet is ready to start vehicle diagnosis.

#### 4.1.1.1 Vehicle Connection

The method used to connect the VCI device to a vehicle's DLC depends on the vehicle's configuration as follows:

- A vehicle equipped with an On-board Diagnostics Two (OBDII) management system supplies both communication and 12-volt power through a standardized J-1962 DLC.
- A vehicle not equipped with an OBDII management system supplies communication through a DLC connection, and in some cases supplies 12-volt power through the auxiliary power outlet adapter receptacle or a connection to the vehicle battery.

#### **OBDII Vehicle Connection**

This type of connection only requires the main cable without any additional adapter.

#### > To connect to an OBDII vehicle

- 1. Connect the main cable's female adapter to the Vehicle Data Connector on the VCI device, and tighten the captive screws.
- 2. Connect the cable's 16-pin male adapter to the vehicle's DLC, which is generally located under the vehicle dashboard.

## 

The vehicle's DLC is not always located under the dashboard. Refer to the user manual of the test vehicle for additional connection information.

#### Non-OBDII Vehicle Connection

This type of connection requires both the main cable and a required OBDI adapter for the specific vehicle being serviced.

There are three possible conditions for non-OBDII vehicle connection:

- DLC connection supplies both communication and power.
- DLC connection supplies communication, and power is to be supplied via the auxiliary power outlet adapter connection.
- DLC connection supplies communication, and power is to be supplied via connection to the vehicle battery.
- > To connect to a non-OBDII vehicle
  - 1. Connect the main cable's female adapter to the Vehicle Data Connector on the VCI device, and tighten the captive screws.
  - 2. Locate the required OBDI adapter and connect its 16-pin jack to the main cable's male adapter.
  - 3. Connect the attached OBDI adapter to the vehicle's DLC.

#### 

Some vehicles may have more than one adapter or may have test leads instead of an adapter. Make the proper connection to the vehicle's DLC as required.

#### > To connect the auxiliary power outlet adapter

- 1. Plug the DC power connector of the auxiliary power outlet adapter into the DC power supply input port on the device.
- 2. Connect the male connector of the auxiliary power outlet adapter into the vehicle's auxiliary power outlet adapter receptacle.

#### > To connect the clamp cable

1. Connect the tubular plug of the clamp cable to the male connector of the auxiliary power outlet adapter.



#### Figure 4-1 Connection Between Auxiliary Power Outlet Adapter and Clamp Cable

- 2. Plug the DC power connector of the auxiliary power outlet adapter into the DC power supply input port of the VCI device.
- 3. Connect the clamp cable to the vehicle's battery.

#### 4.1.1.2 VCI Connection

After the VCI device is properly connected to the vehicle, the Power LED on the VCI device lights solid green and a beep sound will be heard, indicating it is ready to establish a communication with the tablet.

Coming with the MaxiSys tablet tool kit, the VCI device supports three communication methods with the tablet: Bluetooth, Wi-Fi, and USB cable.

#### Pairing Up via Bluetooth

In open areas, the working range for Bluetooth communication is about 328 feet (100 m), giving technicians greater mobility to perform vehicle diagnosis from anywhere in the repair shop.

To expedite multi-vehicle diagnostics, more than one VCI can be used in busy repair shops, enabling technicians to quickly pair their MaxiSys tablet to each VCI via Bluetooth separately, therefore eliminating the need to unplug the VCI from one vehicle and then connect it to another each time.

#### > To pair the tablet with the VCI device via Bluetooth

- 1. Power up the tablet.
- 2. Select the VCI Manager application from the MaxiSys Job Menu.
- 3. Select **VCI BT** from the connection mode list and tap the Bluetooth toggle to turn it **ON**. The device automatically scans for available VCI devices for

Bluetooth pairing. The found devices are listed in the setting section on the bottom-right of the screen.

#### 

If no VCI device is found, this may indicate that the signal strength is too weak to be detected. Reposition the VCI device and remove all possible objects that may cause signal interference. Tap the **Scan** button at the top-right corner of the screen to rescan for VCI devices.

- 4. Typically, the VCI device name displays as "Maxi" suffixed with a serial number. Select the VCI device for pairing. (If more than one VCI is used, ensure the correct VCI is selected to pair.)
- 5. When the pairing is successful, the connection status displays as "Connected."
- 6. The VCI Manager Shortcut on the bottom of the screen displays a green circle BT icon when the tablet and the VCI are connected.

Refer to VCI Bluetooth Pairing for additional information.

#### Wi-Fi Connection

The VCI device supports 5 GHz Wi-Fi connection. In open areas, the working range of 5G Wi-Fi communication is up to 164 feet (50 m).

#### > To pair the tablet with the VCI device via Wi-Fi

- 1. Power up the tablet.
- 2. Select the VCI Manager application from the MaxiSys Job Menu.
- Select Wi-Fi from the connection mode list and tap the Wi-Fi toggle to turn it ON. The tablet automatically scans for available VCI devices for Wi-Fi connection. Found VCI devices are listed in the setting section on the bottomright of the screen.
- 4. Typically, the VCI device name displays as "Maxi" suffixed with a serial number. Select the required device for connection.
- 5. When the pairing is successful, the connection status is shown as "Connected."
- 6. The VCI Manager Shortcut on the bottom of the screen displays a green circle Wi-Fi icon when the tablet and the VCI are connected.

Refer to Wi-Fi Connection for additional information.

#### **USB Cable Connection**

The USB cable connection is a simple and quick way to establish a communication between the tablet and the VCI device. After properly connecting the USB cable from the tablet to the VCI device, the VCI Manager Shortcut on the bottom of the screen displays

a green check mark and the Connection LED on the VCI device lights solid green, indicating the connection between the devices is successful. The MaxiSys diagnostics tablet is now ready to perform vehicle diagnosis.

#### **NOTE**

Since the USB connection provides the most stable communication and is therefore the recommended communication method between the tablet and VCI when operating ECU programming or coding. The USB communication method will take priority over other connected communication methods.

#### 4.1.1.3 No Communication Message

- A. If the tablet is unable to connect to the VCI, an "Error" message displays. An "Error" message indicates the tablet is not communicating with the VCI device. Troubleshoot the error by performing the following steps:
  - Ensure the VCI device is powered on.
  - When using the wireless connection, ensure the network is configured correctly and the proper device has been connected.
  - If the tablet loses communication abruptly during the diagnosis, ensure no objects are causing signal interruption.
  - Ensure the VCI device is properly positioned with the VCI front side up.
  - Move the tablet closer to the VCI device. If using the wired connection, ensure the cable is securely attached to the VCI.
  - Ensure the VCI communication mode is lit for the selected communication type: Bluetooth, Wi-Fi, or USB cable.
- B. If the VCI device is unable to establish a communication link, a message will display troubleshooting instructions. Possible causes for the communication error include:
  - The VCI device is unable to establish a communication link with the vehicle.
  - A vehicle system has been selected for diagnosis that is not supported by the vehicle.
  - There is a loose connection.
  - There is a blown vehicle fuse.
  - The vehicle or the data cable has a wiring fault.
  - There is a circuit fault in the data cable or adapter.
  - The vehicle identification is incorrectly entered.
# 4.2 Getting Started

Prior to first use of the Diagnostics application, ensure the VCI device is properly connected to and is communicating with the tablet. See *Establish Vehicle Communication* for further details.

# 4.2.1 Vehicle Menu Layout

When the VCI device is properly connected to the vehicle via the main cable, and paired to the tablet, the platform is ready to start vehicle diagnosis. Tap the **New Energy** application button on the MaxiSys Job Menu. The Vehicle Menu displays on the screen.



Figure 4-2 Vehicle Menu Screen

- 1. Top Toolbar Buttons
- 2. Manufacturer Icons

### 4.2.1.1 Top Toolbar Buttons

The operations of the toolbar buttons at the top of the screen are listed and described in the table below:

Table 4-1 Top Toolbar Buttons					
Button	Name	Description			
	Home	Returns to the MaxiSys Job Menu.			
VID	VID	<ul> <li>Tap this button to open a dropdown list:</li> <li>Tap Auto Detect for auto VIN detection.</li> <li>Tap Manual Input to enter VIN code or license number manually.</li> <li>Tap Scan VIN/License to scan the VIN code/license number by camera.</li> </ul>			
All	All	Displays all the vehicle makes in the vehicle menu.			
Favorites	Favorites	Displays user-selected favorite vehicle makes.			
History	History	Displays the stored test vehicle history records. This option provides direct access to the previously tested vehicle recorded during previous test. See <i>Vehicle History</i> .			
USA	USA	Displays the American vehicle menu.			
European	European	Displays the European vehicle menu.			
Asia	Asia	Displays the Asian vehicle menu.			
China	China	Displays the Chinese vehicle menu.			
QSearch	Search	Tap inside the search field to display a virtual keyboard and input the vehicle manufacturer to test.			

Table 4-1 Top Toolbar Buttons

Button	Name	Description
Cancel	Cancel	Tap this button to exit the search screen or to cancel an operation.

### 4.2.1.2 Manufacturer Icons

The manufacturer icons display the various vehicle brands. Select the manufacturer icon after the VCI device is properly connected to the test vehicle to start a diagnostic session.

# 4.3 Vehicle Identification

The MaxiSys diagnostic system supports four methods of vehicle identification.

- 1. Auto Detect
- 2. Manual Input
- 3. Scan VIN/License
- 4. Manual Vehicle Selection

## 4.3.1 Auto Detect

The MaxiSys diagnostic system features the latest VIN-based Auto Detect function to identify CAN vehicles with just one tap, enabling the technician to quickly identify the exact vehicle and scan its available systems for fault codes.

### > To perform Auto Detect

- 1. Tap the **New Energy** application button from the MaxiSys Job Menu. The Vehicle Menu displays.
- 2. Tap the **VID** button on the top toolbar. Select **Auto Detect**. The tablet starts VIN scanning on the vehicle's ECU. Once the test vehicle is successfully identified, the system will guide you to the New Energy Main Menu screen.



Figure 4-3 VID Screen

# 4.3.2 Manual Input

For vehicles that do not support the Auto Detect function, the MaxiSys diagnostic system allows you to enter the vehicle VIN or license number manually, or simply take a photo of the VIN sticker or license plate for quick vehicle identification.

- > To perform Manual Input
  - 1. Tap the **New Energy** application button from the MaxiSys Job Menu. The Vehicle Menu displays.
  - 2. Tap the VID button on the top toolbar.
  - 3. Select Manual Input.
  - 4. Tap the input box and enter the correct VIN code or license number.
  - 5. Tap **OK**. The vehicle will be identified and matched to the vehicle database, and the system will guide you to the New Energy Main Menu screen.

# 4.3.3 Scan VIN/License

Tap **Scan VIN/License** in the dropdown list (see *Figure 4-3 VID Screen*), the camera will be opened. On the right side of the screen, from top to bottom, three options are available: **Scan Bar Code**, **Scan VIN**, and **Scan License**.

### 

The method of Scan License is supported in some countries and areas. Please manually input the license number if it is not available.

Select one of three options and position the tablet to align the VIN or license number within the scanning window, the result displays in the Recognition result dialog box after scanned. Tap **OK** to confirm the result, and then the vehicle information confirmation screen will display on the tablet. If all the vehicle information is correct, tap the icon in the middle of the screen to confirm the VIN of the vehicle being tested, tap **OK** to continue.



Figure 4-4 Scan VIN Code

If the VIN/License number cannot be scanned, please manually input the VIN/License number. Tap **OK** to continue. Confirm the VIN of the vehicle being tested to proceed.

# 4.3.4 Manual Vehicle Selection

When the vehicle's VIN is not automatically retrievable through the vehicle's ECU, or the specific VIN is unknown, you can select the vehicle manually.

### Step-by-step Vehicle Selection

This mode of vehicle selection is menu-driven. Select a vehicle manufacturer on the Diagnostics Vehicle Menu screen and the Acquire VIN Information screen displays, then tap the **Manual Selection** button. Select the vehicle information like the Brand, Model, Capacity, Engine type, and Model year on the same screen. The **ESC** button at the lower-right corner of the screen will bring you back to the previous screen. Tap the **Reset** button to reselect the vehicle information if needed.

# 4.4.1 New Energy Screen Layout

After vehicle information is confirmed, tap **OK** to enter the main diagnostic program. This section describes common functions, including Auto Scan, Control Unit, HV System Diagnosis, Service, and Programming. The available functions may vary among different vehicles.



Figure 4-5 New Energy Main Menu Screen

- 1. New Energy Toolbar
- 2. Current Directory Path
- 3. Status Information Bar
- 4. Main Section
- 5. Function Buttons

### 4.4.1.1 New Energy Toolbar

The new energy toolbar contains buttons that allow you to print or save the displayed data and perform other operations. The table below provides a brief description for the operations of the new energy toolbar buttons:

Button	Name	Description
	Home	Tap to return to MaxiSys Job Menu.
¢4	Vehicle Swap	Exits the diagnostic session and returns to the vehicle menu screen to select another vehicle for testing.
\$	Settings	Opens the Settings screen. See Settings.
<b>e</b>	Print	Saves and prints a copy of the displayed data. See <i>Print Settings</i> .
	Help	Provides instructions or tips for operations of various diagnostic functions.
Ð	Save	Opens a submenu which provides options for data storage.
, M	Data Logging	Use this function when encountering an error while testing or diagnosing a vehicle. This function will record the communication data and ECU information of the test vehicle and send it to Autel's technical staff to review and provide solution. Go to the Support application to follow up the processing progress. See <i>Data Manager</i> .

#### Table 4-2 New Energy Toolbar Buttons

#### > To print data in New Energy

- 1. Tap the **New Energy** application on the MaxiSys Job Menu. The **Print** button on the new energy toolbar is available throughout all New Energy operations.
- 2. Tap **Print** and a drop-down menu displays.
  - a) **Print This Page** prints a screenshot copy of the current screen.
  - b) **Print All Data** prints a PDF copy of all displayed data.
- 3. A temporary file will be created and sent via the computer to the printer.
- 4. When the file is sent, a confirmation message displays.

# 

Make sure the tablet and the printer are connected either by Wi-Fi or LAN before printing. For more instructions on printing, see *Print Settings* for details.

### > To submit Data Logging reports in New Energy

- 1. Tap the **New Energy** application on the MaxiSys Job Menu. The **Data Logging** button on the new energy toolbar is available throughout all New Energy operations.
- 2. Tap the **Data Logging** button to display the error options. Select a specific error, then tap **OK**, and a submission form will display to let you fill in the report information.
- 3. Tap the **Send** button in the upper-right corner of the screen to submit the report form via the Internet. A confirmation message displays when sent successfully.

## 4.4.1.2 Current Directory Path

The current directory path shows all directory names to access the current page.

### 4.4.1.3 Status Information Bar

The status information Bar at the top-right of the Main Section displays the following items:

- 1. Network Status Icon indicates whether a network is connected.
- 2. **VCI Icon** indicates the communication status between the tablet and the VCI device.
- 3. Battery Icon indicates the battery status of the vehicle.

### 4.4.1.4 Main Section

The main section varies depending on the stage of operations which shows vehicle identification selections, the main menu, test data, messages, instructions, and other diagnostic information.

### 4.4.1.5 Function Buttons

The function buttons displayed at the bottom of the screen vary by operation. Function includes navigation, reporting, and code clearing. The functions of these buttons will be described in the following sections when relevant.

## 🖉 NOTE

The new energy toolbar (located on the top of the screen) will be active throughout the diagnostic session for tasks such as printing and saving the displayed data, obtaining help information, or performing data logging.

# 4.4.2 Screen Messages

Messages display when additional input is needed before proceeding. There are mainly three main types of on-screen messages: Confirmation, Warning, and Error.

## 4.4.2.1 Confirmation Messages

This type of messages usually displays as an "Information" screen, when you are about to perform an action that cannot be reversed or when an action has been initiated and your confirmation is needed to continue.

When a user-response is not required, the message displays briefly.

### 4.4.2.2 Warning Messages

This type of messages displays when completing the selected action may result in an irreversible change or loss of data. An example of this message is the "Erase Codes" message.

### 4.4.2.3 Error Messages

Error messages display when a systemic or procedural error has occurred. Possible errors include cable disconnection and communication interruption.

# 4.5 Diagnostics Menu

The New Energy application enables you to establish a data connection with the vehicle's ECU through the VCI device for vehicle diagnosis and maintenance.

The Main Menu screen (see *Figure 4-5 New Energy Main Menu Screen*) navigates users to perform read codes, clear codes, or perform comprehensive automotive diagnostic functions, and so on. After the function is selected, the tablet will establish a communication with the vehicle through the VCI device, and enter the corresponding function menu or selection menu based on your selection.

# 4.6 Diagnostics Functions

## Auto Scan

The Auto Scan function, which can be used to start auto scanning for all the available systems on the vehicle, will be listed on the navigation bar when accessing diagnostics function.

On the Auto Scan screen, there are two tabs: Topology Tab and List Tab.

A. Topology Tab Page

For a number of vehicle brands, including Volkswagen, Audi, BMW, Ford, Land Rover, Jaguar, Chrysler, Fiat, and Volvo, a topology map is available to display the relationship between vehicle systems. The Topology Tab page displays a system distribution diagram of the vehicle control modules.



Figure 4-6 Topology Tab Page

### B. List Tab Page

The List Tab page is available for most vehicles.

-	and a second	1000				 		VCb	12.3
10	pology	List							ß
1	Engine c	ontrol module					Not scann	ned	
2	Transmis	ssion control r	nodule				Not scanr	ned	1100
3	Electroni	c brake contro	ol module				Not scann	ned	
4	Inflatable	e restraint sen	sing and di	iagnostic n	nodule		Not scann	ned	1100
5	Instrume	ent cluster					Not scann	ned	-
6	Power st	eering contro	l module				Not scanr	ned	1180-
7	Steering	column lock o	control mod	dule			Not scann	ned	
8	Steering	wheel angle s	ensor mod	ule			Not scanr	ned	1100
9	Fuel pur	np control mo	dule				Not scann	ned	

Figure 4-7 List Tab Page

- 1. Main Section
  - A. When displayed in a topology map

The ECU system of the tested vehicle is displayed in the form of a topology diagram, which describes the layout of the cables and systems of the vehicle control circuit and the path used for data transmission. Tap **Fault Scan** from the function buttons. The number of total faults will appear on the upper-right corner and the results will be displayed in different colors after scanning:

- Green: the system has detected no faults.
- Gray: the system has not received a response.
- Blue: the system has not been scanned.
- Orange: the system has detected faults. The number of faults appears on the upper-right corner of the system.



### Figure 4-8 Scan Results in Topology Tab Page

- B. When displayed in a list
  - Column 1 displays the system numbers
  - Column 2 displays the scanned systems

### **NOTE**

The HV system/ADAS icon will appear on the right side of HV system/ADAS system.

- Column 3 displays the scan results
  - Fault | #: Indicates there is/are detected fault code(s) present; "#" indicates the quantity of detected faults.
  - Pass | No Fault: Indicates the system was scanned and no fault has been detected.
  - ♦ Not Scanned: Indicates the system has not been scanned.
  - ♦ No Response: Indicates the system has not received a response.
- Column 4 tap the solution to enter a system for performing further diagnostics.

BMV V10.0		<b>M</b>	2 1	۵	0	B			
BMW	> Automatic select	tion > Auto scan						VCb	-+ 12.2
То	pology	List			DTCs: 18	_		-	100% 🗹
1	ABS-DSC (	ABS-Dynamic	Stability Contr	ol)			Fault   1	$\odot$	
	D359DF		age (relative tim er KOMBI	e BN2020, 276.2.8)	, receiver DSC		Intermittent		
2	KOMBI (Ins	strument Clus	ter)				Fault   2	$\bigcirc$	**
	<u>026004</u>	Instrume	nt panel: Coding	Internal SWT chec	k failed		Permanent		
	026003	Instrume	nt panel: Coding	External SWT test	condition not	met	Permanent		
3	ZGM (Cent	tral Gateway N	/lodule)				Fault   1	$\bigcirc$	**
	CD0600	ZGM: Eth	ernet: Physical f	ault.			Permanent		
4	TEE1 (Elec	tric-Machine	Electronics)			A	Fault   1	$\bigcirc$	
	CE15F8	No mess	age, receiver EM	E, transmitter KOM	BI		Intermittent		
VIN: Info: Bh	MVX/03_/000/EUR_L	L		Report	Quick erase	Fault scan	Enter system		ESC

Figure 4-9 Scan Results in List Tab Page

2. Function Buttons

The table below provides a brief description of the function buttons:

Name	Description
Report	Displays the diagnostic data in report form.
Quick Erase	Erases all fault information after scanning.
Fault Scan	Scans vehicle system modules.
Pause	Pauses the scanning process.
Enter System	Enters the ECU system.
ESC	Returns to the previous screen or exits Diagnostics screen.

Table 4-3 Function Buttons in Auto Scan Screen

### > To perform an Auto Scan function

Take topology as an example:

- Tap the New Energy application button on the MaxiSys Job Menu. Choose the corresponding vehicle information and enter the Main Menu screen (see Figure 4-5 New Energy Main Menu Screen).
- 2. Select Auto Scan from the navigation bar.
- 3. The topology map displays in the main section. Tap the **Fault Scan** button at the bottom of the screen to scan the vehicle system modules.

# **Control Unit**

The Control Unit function allows you to manually locate a required control system for testing through a series of choices. Simply follow the menu-driven procedures, and make proper selection each time; the program will guide you to the diagnostic function menu after a few choices you've made.

BMW V10.00	¢ 22 (	🖶 🖉 🖻					
BMW > Automatic selection > Auto s	scan > KOMBI (Instrument Cluster)		<b>(b) VCb □</b> 12.2V				
KOMBI (Instrument Cluster)							
	K	~					
ECU information	Trouble codes	Live data	Active test				
VIN: Info: BMW/X/XCL_/G08/EUR_LL			ESC				

#### Figure 4-10 Control Unit Screen

Available functions may vary by vehicle. The function menu may include:

- **ECU Information** displays detailed ECU information. Select to display information screen.
- **Trouble Codes** contains Read Codes and Erase Codes. The former displays detailed DTC information retrieved from the vehicle control module. The latter facilitates you to erase DTCs and other data from the ECU.
- Live Data retrieves and displays live data and parameters from the vehicle's ECU.
- Active Test provides specific subsystem and component tests. This selection may display as *Actuators, Actuator Test,* or *Function Tests*. Available tests vary by vehicle.
- Special Functions provides component adaptation or variant coding functions for custom configurations, and allows entry of adaptive values for certain components after repairs. Depending on the test vehicle, this selection may sometimes appear as Control Unit Adaptations, Variant Coding, Configuration, or something similar.

# 4.6.1 ECU Information

This function retrieves and displays the specific information for the tested control unit, including unit type, version numbers, and other information.

E	CU information
Production date (day, month, year)	09.02.12
Supplier	Blaupunkt
Programming date (day, month, year)	23.09.17
ilometer reading when programming	655350

### Figure 4-11 ECU Information Screen

- 1. New Energy Toolbar see *Table 4-2 New Energy Toolbar Buttons* for detailed descriptions of the operations of each button.
- 2. Current Directory Path
- 3. Status Information Bar
- 4. Main Section the left column displays the item names; the right column displays the specifications or descriptions.
- Function Button in this case, only an ESC button is available; tap it to exit after viewing.

# 4.6.2 Trouble Codes

The Freeze Frame, Read Codes, and Erase Codes function buttons are contained in the Trouble Codes screen. The Freeze Frame button will be activated if there are freeze frame data for viewing. Tap the **Erase Codes** button to erase DTCs and other data from the ECU, while tapping the **Read Codes** button to display the detailed DTC information retrieved from the vehicle control module. When tapping **Trouble Codes** from the navigation bar of the Control Unit screen, the tablet will automatically read the DTC information in ECU.

DTC Status	Description
02100 Permanent	ZGM: transport mode active
CD040A Permanent	ZGM, PT-CAN: communication fault
CD041F Permanent	ZGM, FlexRay: line fault on path 0
CD0423 Permanent	ZGM, FlexRay: line fault on path 2
CD1400 Permanent	Message (vehicle condition) incorrect, receiver ZGM, transmitter FEM-ZGM / JBE / CAS / DME
	Freeze Erase Read

Figure 4-12 Trouble Codes Screen

- 1. New Energy Toolbar see *Table 4-2 New Energy Toolbar Buttons* for detailed descriptions of the operations of each button.
- 2. Current Directory Path
- 3. Status Information Bar
- 4. Main Section
  - Column 1 displays the retrieved codes from the vehicle
  - Column 2 indicates the status of the retrieved codes
  - Column 3 displays detailed descriptions for the retrieved codes
- 5. Function Buttons
  - Freeze Frame a snowflake icon appears when freeze frame data is available for viewing. Tap the button to display data screen. The Freeze frame screen is similar to that of the Read codes screen and share similar operations.
  - **Search** tap to search the selected DTC for additional information on the Internet.
  - **Erase Codes** tap to erase codes from the ECU. It is recommended to read DTCs and make necessary repairs before erasing the codes.

After reading the retrieved codes from the vehicle and certain repairs have been made, you can erase the codes from the vehicle using this function. Before performing this function, make sure the vehicle's ignition key is in the ON (RUN) position with the engine off.

### > To erase codes

- 1. Tap **Erase Codes** from the function buttons.
- 2. A warning message displays to inform you of data loss when this function is applied.
  - ✤ Tap Yes to continue. A confirming screen displays when the operation is successfully done.
  - ♦ Tap No to exit.
- 3. Tap **ESC** on the confirming screen to exit Erase Codes screen.
- 4. Check the Read Codes function again to ensure the operation is successful.
- Read Codes retrieves and displays the DTCs from the vehicle control system. The Read Codes screen varies for each vehicle being tested.
- ESC tap it to return to the previous screen or exit the function.

# 4.6.3 Live Data

When this function is selected, the screen displays the data list for the selected module. The parameters display in the order that they are transmitted by the ECU, so expect variation among vehicles.

Gesture scrolling allows you to quickly move through the data list. Touch the screen and drag your finger up or down to reposition the parameters being displayed if the data occupies more than one screen. The figure below displays a typical Live Data screen:

(1)	Name 💿 û ilems seleciej	Value	Units
Ŭ	Currently available energy of the high-voltage battery	60.11	kWh
	$\hfill \square$ Available energy when high-voltage battery is fully charged $\hfill \bigcirc$	74.23	kWh
	Average charge state O	12.8	%
	Min. charge state 🔍	83.28	%
	Max. charge state 🔍	83.66	%
2	□ High voltage battery current (-' discharge; '+' charge)   ©	-1.11	А
	Single cell voltage min./max. O	4.03	v
	□ Single cell voltage min./max.1 ♀	4.04	v
	Voltage at high voltage battery	379.33	v
l	Voltage of the high-voltage intermediate circuit	379.51	v
3-	Cancel All Show Graph Merge To Top Setting Clear Data Freeze	Record	Review Back

Figure 4-13 Live Data Screen

- New Energy Toolbar tap the drop-down button at the top center of the screen and the new energy toolbar buttons will display. See *Table 4-2 New Energy Toolbar Buttons* for detailed descriptions of the operations of each button.
- 2. Main Section
  - Name Column displays the parameter names.
    - Check Box tap the check box to the left of a parameter to select the item.
       Tap the check box again to deselect it.
    - Drop-down Button tap the drop-down button on the right side of a parameter to open a submenu that provides optional modes in which to display the data.
  - Value Column displays the values of the parameters.
  - Range Column displays the ranges of the parameters.
  - Unit Column displays the unit for the parameter values. When you need to change the unit mode, tap the **Settings** button on the diagnostics toolbar and select a required mode. See *Unit*.
- a) Display Mode

There are four types of display modes available for data viewing, allowing you to view various types of parameters in the mode best suited to represent the data.

Tap the drop-down button on the right side of a parameter to open a submenu. A total of 7 buttons will be displayed: the 4 buttons on the left represent different data display modes, plus one **Information** button (active when additional information is available), one **Unit Change** button (for switching the unit of displayed data), and one **Trigger** button (for opening the Trigger Settings window).

Name 💿 0 items selected	Value	Units
$\square$ Currently available energy of the high-voltage battery $\square$	60.11	kWh
Available energy when high-voltage battery is fully charged $ \heartsuit $	74.23	kWh
Average charge state	12.8	%
<u>∧ A ⊭ ■ ()</u> 4	0	%
		%
High voltage battery current ('-' discharge; '+' charge) 🛇	-1.11	А
Single cell voltage min./max. O	4.03	v
Single cell voltage min./max.1	4.04	v
Voltage at high voltage battery	379.33	v
$\square$ Voltage of the high-voltage intermediate circuit $~ \bigcirc$	379.51	v
Cancel All Show Graph Merge To Top Setting Clear Data Freeze	e Record F	Review Back

Figure 4-14 Display Mode Screen

Each parameter item displays the selected mode independently.

- ♦ Analog Gauge Mode displays the parameters in gauge charts.
- ♦ Text Mode the default mode that displays the parameters as a text list.

## **NOTE**

Status parameters, such as a switch reading like ON, OFF, ACTIVE, and ABORT can only be displayed in Text Mode. Value parameters, such as a sensor reading, can be displayed in both text and graph modes.

Waveform Graph Mode — displays the parameters in waveform graphs. In this mode, five control buttons will display on the right side of the parameter item, allowing you to manipulate the display status.

Name 🌖 1 items selected	Value	Units
$\Box$ Currently available energy of the high-voltage battery $ igodot$	60.11	kWh
Available energy when high-voltage battery is fully charged $$ $$	74.23	kWh
✓ Average charge state (%) © SetY	12.8 ×1 🔍 X	. <sub>×1</sub> @,γ
×		K 7
C 0021 0022 0024 0025	0025 3027	0028
Min. charge state O	83.28	%
Max. charge state	83.66	%
High voltage battery current (-' discharge; '+' charge) 🔍	-1.11	A
Single cell voltage min./max. O	4.03	v
Single cell voltage min./max.1 ©	4.04	v
Cancel All Show Graph Merge To Top Setting Clear Data Freeze	Record F	Review Back

### Figure 4-15 Waveform Graph Mode Screen

- 1) Settings Button (SetY) sets the minimum and maximum value of the Y axis.
- Scale Button changes the scale values. There are four scales available for the X axis: x1, x2, x4 and x8. There are three scales available for the Y axis: x1, x2, and x4.
- 3) Edit Button edits the waveform color and the line thickness.
- 4) **Zoom-in Button** tap once to display the selected data graph in full screen.
- 5) **Exit Button** tap to exit the waveform graph mode.

**Full Screen Display** — this option is only available in the waveform graph mode, and mostly used in Graph Merge status for data comparison. There are four control buttons available on the top-right side of the screen under this mode.

• Scale Button — tap to change the scale values below the waveform graph.

There are four scales available for the X axis: x1, x2, x4 and x8. There are three scales available for the Y axis: x1, x2, and x4.

- Edit Button tap to open an edit window, in which you can set the waveform color and the line thickness displayed for the selected parameter item.
- Zoom-out Button tap to exit full screen display.
- Exit Button tap to exit the waveform graph mode.
- > To edit the waveform color and line thickness
  - 1. Select parameter items to display in Waveform Graph mode.
  - 2. Tap the Edit Button, and an edit window displays.



### Figure 4-16 Waveform Edit Screen

- 3. The parameter item is selected automatically in the left column.
- 4. Select a color from the second column.
- 5. Select a line thickness from the right column.
- 6. Tap **Done** to save the setting and exit, or tap **Cancel** to exit without saving.

### **NOTE**

In full screen display, please edit the waveform color and line thickness by tapping the **Edit** button on the top-right side of the screen.

♦ Digital Gauge Mode — displays the parameters in the form of a digital gauge graph.

#### b) Trigger Settings

On the trigger settings screen, you can set a standard range by filling in a minimum value and a maximum value. When exceeding this range, the trigger function will be executed

and the device will automatically record and save the generated data. You can check the saved live data by tapping the **Review** button at the bottom of the screen.

Tap the drop-down button on the right side of the parameter name to open a submenu. The **Trigger** button is the last one in the submenu. Tap to display the trigger setting window.

Name 💿 1 items select	Value	Units	
Currently available energ	60.11	kWh	
Available energy when hi	74.23	kWh	
Verage charge state	Trigger Settings	12.8	%
🗌 Min. charge state 🔍	Trigger ON	83.28	%
🗆 Max. charge state 🔍	Buzzer alarm	83.66	%
High voltage battery cur	D.O	-1.11	А
Single cell voltage min./	мах	4.03	v
Single cell voltage min./	20.0	4.04	v
Uoltage at high voltage	Cancel OK	379.33	v
Voltage of the high-volta	ge intermediate circuit 🔍	379.51	v
	🖭 春 🔅 💼 🚯		🕑 🔦
Cancel All Show G Selected	raph Merge To Top Setting Clear Data Freez	e Record F	Review Back

Figure 4-17 Trigger Settings Screen

Two buttons and two input boxes are available in the Trigger Settings window.

- a) Trigger On switches the trigger on and off. The trigger is ON by default.
- b) Buzzer Alarm switches the alarm on and off. The alarm function makes a beep sound as an alert when the data reading reaches the preset minimum or maximum point. The buzzer alarm will only sound at the first trigger.
- c) MIN tap this input box to display a virtual keyboard to enter the required lower limit value.
- d) MAX tap this input box to display a virtual keyboard to enter the required upper limit value.
- > To set a trigger
  - 1. Tap the drop-down button on the right side of the parameter name to open a submenu.
  - 2. Tap the **Trigger** button on the right side of the submenu to open the trigger settings window.
  - 3. Tap the **MIN** input box and enter the required minimum value.
  - 4. Tap the **MAX** input box and enter the required maximum value.
  - 5. Tap **OK** to save the setting and return to the Live Data screen; or tap **Cancel** to

exit without saving.

When the trigger is successfully set, a trigger mark displays in front of the parameter name. The mark is gray when it is not triggered, and displays orange when triggered. Moreover, two horizontal lines display on each of the data graphs (when Waveform Graph Mode is applied) to indicate the alarm point. The limit lines are shown in different colors to differentiate them from the parameter waveforms.

### 3. Function Buttons

The operations of the available functional buttons on the Live Data screen are described below:

- ♦ Cancel All tap this button to cancel all selected parameter items. Up to 50 parameters can be selected at one time.
- Show Selected/Show All tap this button to switch between the two options; one displays the selected parameter items, and the other displays all the available items.
- ♦ Graph Merge tap this button to merge selected data graphs (for Waveform Graph Mode only). This function is very useful when comparing different parameters.

# **NOTE**

This mode supports Graph Merge of 2 to 5 parameters that can be represented digitally. Non-digital parameters are not supported.

### > To merge selected data graphs

- 1. Select parameter items to be merged.
- 2. Tap the Graph Merge button at the bottom of the Live Data screen.
  - a) This mode only supports parameters that can be represented digitally. If non-digital parameters are selected, a message will display advising the user that the selected parameters are not supported in this mode and to select 2 to 5 digital parameters. Tap the **Got It** button to return to the previous screen and select supported parameters.
  - b) If parameters are selected that are not supported in this mode, a message will display advising the user to selected only parameters that are supported. A message will also display if more than 5 parameters have been selected. Please select 2 to 5 of the supported parameters and tap the **OK** button to merge.
- 3. Tap the **Cancel Merging** button at the bottom of the Live Data screen to cancel merge.
- ✤ To Top moves a selected data item to the top of the list.
- ♦ Setting tap this button to set recording duration.

### > To set live data record duration

- 1. Tap the **Setting** button at the bottom of the Live Data screen.
- 2. Tap the > button to the right of **Recording time after trigger** bar and select a time length.
- 3. Tap **OK** to save the setting and return to the Live Data Setting screen; or tap the "X" button at the upper-right corner to exit without saving.
- 4. Tap **Done** at the upper-right corner of the Live Data Setting screen to confirm and save the setting, and return to the Live Data screen; or tap **Cancel** to exit without saving.
- ♦ Clear Data tap this button to clear all cached live data.
- ♦ Freeze displays the retrieved data in freeze mode.
  - Previous Frame moves to the previous frame of frozen data.
  - Next Frame moves to the next frame of frozen data.
  - Play/Pause tap to play/pause the frozen data.
  - Resume tap to exit the freeze data mode and return to normal data display.
- Record starts recording the live data of the selected data items. Tap the Record button at the bottom of the Live Data screen. A message will display prompting user to select parameters to record. Tap the Got It button to confirm. Scroll down and select data to record. Tap the Record button to start recording. Tap the Resume button to stop recording. The recorded live data can be viewed in the Review section at the bottom of the Live Data screen. The recorded data can also be reviewed in the Data Manager application.
  - Resume Tap this button to stop data recording and to return to normal data display.
  - Flag this button displays when the Record function is applied. Tap this button
    to set flags to note points of interest when recording data. Notes can be added
    during playback in Review or Data Manager. Select the preset flag to open a
    popup window and display a virtual keyboard to input notes.
- ✤ Review review the recorded data. Tap the Review button to display a recording list, and select one item to review.

## 🖉 NOTE

Only the data recorded during the current operation can be reviewed on the Live Data screen. All the historical recorded data can be reviewed in "Review Data" in the Data Manager application.

- Previous Frame switches to the previous frame of recorded data.
- Next Frame switches to the next frame of recorded data.
- Play/Pause tap to play/pause the recorded data.

- Show Selected display the selected parameter items.
- Graph Merge merges selected data graphs.
- Back exits the review, and returns to the Live Data screen.
- ♦ Back returns to the previous screen or exits the function.

# 4.6.4 Active Test

The Active Test function is used to access vehicle-specific subsystem and component tests. Available tests vary by vehicle.

During an active test, the tablet sends commands to the ECU to activate the actuators. This test determines the integrity of the system or part by reading ECU data, or by monitoring the operation of the actuators. Such tests may include switching a solenoid, relay, or switch, between two operating states.

Selecting Active Test displays a menu of test options. Available tests vary by vehicle.

Select a test from menu options. Follow the instructions displayed on the screen to complete test. Procedures and instructions vary by vehicle.

The function buttons in the lower-right corner of the Active Test screen manipulate the test signals. The operational instructions are displayed in the main section of the test screen. Follow the on-screen instructions and make appropriate selections to complete the tests. Tap the **ESC** button to exit the test when finished.

# 4.6.5 Special Functions

Depending on the test vehicle, this selection may sometimes appear as Learning Process, Correction Programming, Emissions Inspection (Not valid for USA), OBD I/M Check (Not valid for USA), or something similar. You can select one to proceed according to your demands.

# 4.7 HV System Diagnostics

This tablet is able to perform diagnosis on high-voltage (HV) system of new energy vehicles. Tap the **New Energy** application to enter the vehicle menu. The icon **enter** tagged on the vehicle makes indicates that the HV system can be diagnosed.

In most cases, HV system list appears on the main screen of HV System Diagnostics. Additionally, a System Block Diagram will be displayed for some new energy vehicles, such as BMW, Tesla, BYD, GM, Audi, Toyota, etc.

Tap HV System Diagnosis on the navigation bar of the Main Menu screen to enter the

interface, which displays the System List and System Block Diagram.

A. System List Page

BMW V10.00 🖄 🏩 🕐 🖻								
BNW > Automatic selection > HV system diagnosis	🌐 VCЬ	=+ 12.2V						
System list System Block Diagram								
SME (Storage Management Electronics) Not scanned								
TEE1 (Electric-Machine Electronics)	Not scanned							
ccu CCU (Combined Charging Unit)	Not scanned							
IHKA (Integrated Automatic Heating And A/C System)	Not scanned							
VN HYE BANYCKICL/GORATIRALL Report Quic eras		ESC						

### Figure 4-18 System List Screen

- Column 1 indicates system icons and names.
- Column 2 indicates scanning status.
- Column 3 tap the button is to enter the system to perform further diagnostic activities.
- > To scan HV systems and clear codes
  - 1. Tap **New Energy** on the MaxiSys Job Menu. Select the corresponding vehicle information to enter the New Energy Main Menu screen.
  - 2. Select HV System Diagnosis on the navigation bar.
  - 3. Tap **Fault Scan** on the bottom of the System List screen to scan the HV system. The quantity of DTCs will show on the upper-right corner of the screen.

BMW V10.00	M	1	<b>\$</b>	•	0	Ð			
BMW > Automatic s	election > HV system di	agnosis						VCL	-+ 12.2
System list	System Block	Diagram			DT	'Cs: 8			1009
TEE1 (E	lectric-Machine	Electronic	s)				Fault   1	$\bigcirc$	**
CE15F8	No mes	sage, receiv	er EME, trai	nsmitter KON	IBI		Intermittent		
ccu (Co	ombined Chargi	ng Unit)					Fault   7	$\bigcirc$	
032198	AC char	AC charging, charging interface, charging plug detection: invalid							
<u>032199</u>		AC charging, charging interface, ready to charge with charge station: cannot be established							
224F81	AC char	ging: Functi	on not avai	lable			Intermittent		
031B92		AC charging, charging function: Charging fault detected by charge management							
032194	Front ch	arging sock	et flap, pos	ition sensor:	Status implau	isible	Intermittent		
0318EA		ging, chargii Itage on AC		ics 2, compo	nent protectio	n:	Intermittent		
VIN: Info: BMW/X/XI3/G08/8	FUR,LL				Report	Quick	Fault		ESC

Figure 4-19 Scan Results of System List

- 4. Tap **Quick Erase** from the Function Buttons. A warning message appears to inform you of potential data loss when this function is applied.
  - a) Tap **Yes** to continue. A confirmation screen appears when the operation is successful.
  - b) Tap No to exit.
- B. System Block Diagram Page

The System Block Diagram Page shows the component layout of the vehicle's HV systems.



Figure 4-20 System Block Diagram Screen

## 4.7.1 System List > SME (Storage Management Electronics)

After scanning the HV systems, select **SME (Storage Management Electronics)**, then tap the button is to enter the SME diagnostic program where you will be able to view battery pack information and perform special functions. The available diagnostic functions will vary among different vehicles.

BMW v10.00	M		Φ.	•	0	B		
BMW > Automatic selection >	HV system	<mark>m diagnosis</mark> > SME (	Storage Manag	ement Electronics	)		ا م	VCb == 12.2V
		SME(S	Storage M	anagement	Electronics)			
		F	0					
Battery Pack Infor.	. 0	Special Fun	ction	0				
VIN: Info: BMW/X/003_/G08/EUR_LL								ESC

Figure 4-21 SME Screen

### **Battery Pack Information**

a) Battery Pack Status

Tap **Battery Pack Information** on the SME screen to get access to the detailed information of the battery pack, including SOC/SOH, total voltage, total current, pack voltage delta, temperature, etc.

### **NOTE**

The available functions displayed in the screen may vary among different battery packs.



Figure 4-22 Battery Pack Status Screen

- 1. New Energy Toolbar see *Table 4-2 New Energy Toolbar Buttons* for detailed descriptions of the operations of each button.
- 2. Current Directory Path
- 3. Status Information Bar
- 4. Main Section

The first row displays the battery pack status:

- **SOC**: State of Charge, reflecting the remaining volume of the battery. When the battery is fully discharged, the value of SOC equals to 0; when the battery is fully charged, the SOC value appears 100%.
- **SOH**: State of Health, indicating functionality status of the battery. 100% means the battery is new and sound and 0% represents the battery is scraped.
- Total Current/Total Voltage: shows the total current and voltage inside of the battery pack and checks whether there is something wrong for current or voltage.

- Pack Voltage Delta: shows voltage difference of cells. The voltage difference of battery cells is one of the essential indicators to reflect battery performance. The smaller the voltage difference is, the better the performance; the larger the voltage difference is, the worse the performance.
- Temperature: indicates temperature of the battery pack. The lifetime and safety
  of battery pack is affected tremendously by temperature. If the temperature is
  too high, it may cause safety issues. If it is too low, it will reduce the lifetime of
  the battery.

The second row displays maintenance recommendations and the quantity of modules.

- Maintenance Recommendations monitors average voltage, differential voltage, maximum and minimum value of modules, providing warnings and maintenance suggestions.
- Number indicates the quantity of modules.

The third row shows the details of each module. Tap each module to view its temperature, voltage difference, voltage of each cell, SOC, and more.

5. Function Buttons — in this screen only Module Location and ESC are available.

Tap **Module Location** to display the location so as to easily position the battery module for troubleshooting. Tap **ESC** to exit the screen.



Figure 4-23 Module Locations Screen

#### b) Battery Pack Information

The Battery Pack Information screen displays battery pack parameters (shown on left column) and specifications (shown on right column).

BMW V10.00	M		•	•	0	B					
BMW > Automatic selectio	n > HV system di	agnosis > SME (!	Storage Manag	ement Electronic	<mark>:s)</mark> > Battery Pack	k Information		VCL	=+ 12.2V		
Battery pa	ck status		Pack Informa	tion		Other live d	ata				
Battery pack para	meters								0		
Number of cells a battery pack	nd series/p	arallel struc	ture in	188 (	2P94S)						
Nominal voltage				345V							
Battery capacity	232A	232Ah									
Battery pack dime	nsion			2228	2228mmx1586mmx311mm						
Battery pack weig	ht			518k	518kg						
Battery pack cooli	ng system i	type		Coola	ant						
Theoretical range				520k	m						
BMS parameters									0		
Production date (	day, month,	year)		09.02	2.12						
VIN: Info: BMW/X/XGL/GOB/EUR_LL									ESC		

### Figure 4-24 Battery Pack Information Screen

#### c) Other Live Data

There are data lists displayed on this screen, including parameter names, values, and units.

Swipe the screen up or down to quickly browse the data list. See *Live Data* for more details.

BMW 10.00	2	•	8	0	B			
BMW > Automatic selection > HV s	ystem diagnosis > SM	AE (Storage Mana)	gement Electronic	:s) > Battery Pack	Information		VCL	=+ 12.2V
Battery pack stat		Other live d	ata					
Name					Valu	ue	U	nits
Coolant circuit valve sta	itus 🔍				not ene	rgised		
Coolant temperature high-voltage battery						7	°C	
Charging contactor release 오						led		
Release, switch contactors						ol of vitch ctors ve		
Service disconnect O						SD1 or loop ed		
Currently available energy of the high-voltage battery						11	kWh	
Available energy when high-voltage battery is fully charged $ igodot$						23	k٧	Vh
VIN: Info: BMW/X/XCL_/COB/EUR_LL								ESC

### Figure 4-25 Other Live Data Screen

# 4.7.2 System Block Diagram

The System Block Diagram screen displays various components and their relations to HV system in the form of block diagram. Each box stands for an individual component of HV system. A HV component or a LV component related to HV control is distinguished by a HV symbol. The components are connected to each other by different lines, which represent HV line circuits, LV line circuits for HV interlocks, power detection circuits, etc. The System Block Diagram may vary among vehicles. This section uses BMW as an example.

### 

Be careful when you work with HV components or LV components related to HV control.



### Figure 4-26 System Block Diagram Screen

Tap the button • on the upper-right corner on the System Block Diagram screen to view detailed information. Tap the button 🗟 on the bottom-right corner to enter full-screen mode. Tap the button again to exit.

- Description describes the profile and terms for easy understanding and use.
- Legend contains Component Code and Component Description.



Figure 4-27 Description Screen



Figure 4-28 Legend Screen

Select a component to view its related information and operation guide, such as Component, Wiring, and Connector. The functions may vary by vehicle. Follow the on-screen guide to complete the operation.



Figure 4-29 Component Screen



Figure 4-30 Wiring Screen



Figure 4-31 Connector Screen

There are some buttons that appear when you enter the Component, Wiring, or Connector screens. The following table will describe those buttons in brief.

Button	Description					
	• <b>Component</b> : tap to open content, including Components, Component Location, Function Description, and Notes.					
	• <b>Wiring</b> : tap to view the component codes and descriptions and search targeted components.					
אא	Tap to enter full screen display.					
як як	Tap to exit full screen display.					
0	Tap to hide irrelevant circuits. Tap again to unhide them.					
$\odot$	Resets the device to factory default settings.					
ESC	Exits the current screen.					

# 4.8 Programming and Coding

Since the introduction of OBDII and leading up to modern hybrids and EVs, hardware and software technologies in cars have been advancing at an exponential rate. Updating software may be the only way to fix the following issues:

- Drivability
- Fuel Efficiency
- Power Loss
- Fault Codes
- Durability of Mechanical Parts

The Programming and Coding function is used to re-flash the vehicle control modules, which allows you to update the computer software of the vehicle to the latest version, as well as to reprogram adaptive data of certain components after making repairs or replacements.

## 

The programming function applies only when the vehicle is connected with a VCI device, which serves as a PassThru interface to establish communication with and transfer data to the vehicle's ECU.

Available programming or coding operations vary by test vehicle. Only the available operations display in the tablet menu.

There are two general types of programming operations:

- A. Coding also known as Teach-in Program, or Component Adaptation, is used to reprogram adaptive data for vehicle control modules after repairs or replacements of vehicle parts.
- B. Reprogramming downloads the latest version of software from the online server database through Internet access (this procedure is done automatically when the tablet is connected to the Internet, so there is no need to check for software updates yourself), and reprograms the newest version into the vehicle's ECU.

## 🖉 NOTE

Ensure that the tablet is connected to a stable internet access before applying the ECU programming function, so that the tablet is able to obtain access to the vehicle manufacturer's server for update service.

Selecting the Programming opens a menu of operation options that vary by vehicle make and model. Selecting a menu option either displays a programming screen or opens another menu of additional choices. Follow the on-screen instructions to operate. How and what information is presented on the screen vary by the type of operation being performed.

# 4.8.1 Coding

The main section of the Coding screen displays a list of vehicle components and the coding information that mainly consists of two parts:

- 1. All available systems for coding are displayed on the left side, and the coding data or value on the right side.
- 2. The bottom of the main section displays the functional buttons that enable you to manipulate the operation.

Check the vehicle condition and the coding information carefully. Use the functional button to edit Codes for the corresponding components. Tap **Send** when you finish editing all items. When the operation is completed, an execution status message such as Completed, Finished or Successful, may display.

Tap the **ESC** button to exit the function.

# 4.8.2 Reprogramming

### Before reprogramming begins:

- It is mandatory that the tablet is connected to a stable Wi-Fi network.
- The tablet must be connected to the VCI device via USB cable.
- The tablet battery must be fully charged during module programming. Connect the tablet to a charger if needed.
- Attach battery maintainer to vehicle battery to ensure a steady voltage is maintained throughout programming. Voltage requirements differ by vehicle manufacturer. Consult vehicle manufacturer recommendations prior to programming a module.
- Do not quit the application during a module reprogramming as the process may fail and may also result in permanent damage to the module.

Typical reprogramming operations require you to input and validate VIN number first. Tap the input box and enter the correct number. The programming interface then displays.

The main section of the reprogramming interface offers information of the hardware, the current software version and the newest software versions to be programmed into the control units.

A series of on-screen operational instructions will display to guide you through the programming procedure.
Carefully read the on-screen information and follow the instruction to execute the programming procedure.

## 4.8.3 Re-flash Errors

## IMPORATANT

When reprogramming onboard, always make sure the vehicle battery is fully charged and in good working condition. During reprogramming, the operation may fail if voltage falls below the proper operation voltage. Sometimes a failed operation can be recovered, but the failed reprogramming can also ruin the control module. We recommend connecting an external battery maintainer to the vehicle to ensure a steady voltage is maintained throughout programming. The required voltage differs by vehicle manufacturer. Consult vehicle manufacturer for correct voltage to be maintained.

Occasionally a flash update procedure may not complete properly. Common causes of flash errors include poor cable connections between the tablet, VCI, and vehicle, the vehicle ignition being switched off before the flash procedure is complete, or low vehicle battery voltage.

If the process quits, recheck all the cable connections to assure good communications and initialize the flash procedure. The programming procedure will automatically repeat if the previous operation does not succeed.

# 4.9 Diagnostic Report

## 4.9.1 Pre-Scan and Post-Scan Functions

After performing pre-scan and post-scan functions by entering the same maintenance order number, tap **Data Manager** > **Vehicle History** to select the historical test record named with the maintenance order number. Both the pre-scan results and post-scan results will be displayed in the same historical test record, which can be generated as a PDF report for easily comparing the changes between pre-scan and post-scan.

#### • Pre-Scan Function

Select and tap a vehicle button from the Vehicle Menu screen. Enter the maintenance order number in the pop-up box to scan and detect the whole vehicle. You can also add pictures to record the current condition of the vehicle. Once the pre-scan is completed, you are not allowed to perform pre-scan again, and the scan result cannot be modified.

### • Post-Scan Function

After the pre-scan is complete, exit the current test vehicle and tap the vehicle button from the Vehicle Menu screen to reconnect again. Enter the same maintenance order number in the pop-up box. The screen for post-scan will display. The postscan record will be generated when the scan is completed. The pre-scan results and post-scan results will be displayed in the same historical test record.

## ⊘ NOTE

The post-scan function can be performed repeatedly. After exiting the vehicle, you only need to tap the vehicle button from the Vehicle Menu screen to reconnect again, then enter the same maintenance order number in the pop-up box and follow the steps to rescan. The last one is the final post-scan result.

## 4.9.2 Diagnostics Report Saving, Viewing, and Sharing

The diagnostic report can be reviewed, saved, and shared with others through many ways.

4.9.2.1 Diagnostics Report Saving

- Via the History function
  - 1) Tap **New Energy** on the MaxiSys Job Menu, and select **History** on the top toolbar.



Figure 4-32 History Screen

2) Select a history record, and tap the •••• button on the upper-right corner.

Title	2016 GM Brazil Corsa-b			View PDF
ehicle Inform	nation			🖶 Print
Year	2016	License pla	ate	🔤 E-mail
Make	GM Brazil	VIN	VIN	
Model	Corsa-b	Odometer	Odometer	
Sub model		Color	Color	Delete
Engine		Status	Not started	
ervice record	1			
Technician				
Technician Notes				
notes				

Figure 4-33 Historical Test Screen

- 3) Tap **Get Report**. Enter the license plate and current mileage. Tap **Save**.
- Via the Auto Scan function
  - 1) Enter the Auto Scan page and tap **Fault Scan** from the function buttons at the bottom of the screen.

BM/		8	0	B		
BMW	> Automatic selection > Auto scan				( <b>b</b> V	Cb 🕂 12.2V
То	pology List					
1	ABS-DSC (ABS-Dynamic Stability Control)				Not scanned	
2	ACSM (Airbag-Advanced Crash Safety Mod	dule)			Not scanned	
3	KOMBI (Instrument Cluster)				Not scanned	
4	RSNR-RL (Left Rear Radar Sensor Near Range)					-
5	RSNR-FR (Right Front Side Radar Sensor N	Not scanned				
6	BDC (Body Domain Controller)				Not scanned	-
7	TRSVC (All Round View Camera)	Not scanned				
8	SME (Storage Management Electronics)					-
9	RSNR-RR (Right Rear Radar Sensor Near R	Not scanned				
VIN Info: BI	NATE/OCL_FOOD/FUR_11	Report	Quick erase	Fault scan		ESC

Figure 4-34 Auto Scan Screen 1

2) When the system scan is completed, tap **Report** from the function buttons at the bottom of the screen.

BMV V10.0			(Fright)	\$	8	0	B			
BMW	> Automatic selection	n > Auto scan							VC	=+ 12.2V
То	pology	List				DTCs: 1	18		-	100% 🗹
1	ABS-DSC (A	BS-Dynamic	Stability C	ontrol)				Fault   1	$\bigcirc$	**
	D359DF		age (relativ er KOMBI	e time BN20	020, 276.2.8	), receiver DS	С,	Intermittent		
2	KOMBI (Inst	rument Clus	ter)					Fault   2	$\bigcirc$	
	<u>026004</u>	Instrume	nt panel: Co	ding: Interr	al SWT che	ck failed		Permanent		
	026003	Instrume	nt panel: Co	ding: Exter	nal SWT tes	t condition no	ot met	Permanent		
3	ZGM (Centra	al Gateway 🛚	/lodule)					Fault   1	$\bigcirc$	
	CD0600	ZGM: Eth	ernet: Phys	ical fault.				Permanent		
4	TEE1 (Electr	ic-Machine	Electronics	5)			▲	Fault   1	$\bigcirc$	
	CE15F8	No mess	age, receive	er EME, tran	smitter KON	1BI		Intermittent		
VIN: Info: 85	MOX703_7080/EUR_LL				Report	Quick erase	Fault scan	Enter system	1	ESC

Figure 4-35 Auto Scan Screen 2

• Via the functions on the new energy toolbar

The diagnostic report can also be viewed from New Energy diagnostics functions screen including Auto scan and Trouble codes. There are two ways to view the saved reports:

- ☆ Tap the button in the new energy toolbar and select Save All Data. Enter the license number and tap Save. Tap the button on the upper-right of the screen to view the report.
- ☆ Tap the button in the new energy toolbar and select **Report to Cloud**. Enter the license number and current mileage. Tap **Save** > **View Report** and then select a saved report to view.

BMW v10.00	M	1000 C	\$	•	0	Ð			
BMW > Automat	ic selection ≻ Auto scan							VCL	=+ 12.2V
		2016_0	07 BMW V	ehicle Diag	<u>ک</u>	Take a Scree	nshot		
	License plate:								
	Make: BMW					Save All Data			
BMW	Year: 2016_07								
	Model: 2//218i_B38								
	Sub model: F45/EUR_LL				ž	Save Report			
	Engine: B38								
	Path: BMW>Automatic s	election>Auto	scan						
	whicle systems have been the report carefully and				faults with	n the number of 7	78. For the sake o	f safet	y driving,
System statu	s report								
System Number					Number of DTCs		Status		
DME (Engine-	Digital Motor Electronic:	5)					7		Fault
EGS (Electron	ic Transmission Manan	ement)					6		Fault
vinc Info: 8MW/2/218LB:	BUT45/EUR_LL								ESC

Figure 4-36 Trouble Codes Screen

## 4.9.2.2 Diagnostics Report Viewing

All the saved reports can be viewed in the Data Manger application.

- ☆ Tap Data Manager > Vehicle History. Select a specific vehicle history record and then tap View PDF in the upper-right corner to view the report.
- Once you save the reports by tapping the Save All Data button, tap Data Manager > PDF to view these reports.
- ♦ Once you save the reports by tapping the Get Report or Save Report button, tap Data Manager > Cloud Report to view these reports.

## 4.9.2.3 Diagnostics Report Cloud Sharing

1) Tap Data Manager > Cloud Report to enter the Report List screen.



Figure 4-37 Report List

## ⊘NOTE

Note that if the report displays  $\bigcirc$ , it means the report has been uploaded to the cloud successfully, and you can share the report with others; if the report displays  $\bigcirc$ , it means the report has failed to upload to the cloud, but will try to automatically upload to the cloud when entering the Report again.

- 2) Tap the  $\leq$  on the lower-right corner of the report.
- 3) There are three ways for report cloud sharing: scan the QR code, send by email, send by SMS (via phone number).

# 4.10 Exit New Energy Application

The New Energy application operates while communication with the vehicle is still active. It is important to properly exit from the diagnostics operation interface to stop all communications with the vehicle before closing the New Energy application.

## 

Damage to the vehicle electronic control module (ECM) may occur if communication is disrupted. Ensure all forms of communication link such as data cable, USB cable, and wireless network or LAN, are properly connected throughout the test. Exit all interfaces before disconnecting the test cable and power supply.

#### > To exit the New Energy application

- 1. On an active diagnostic screen, tap the **Back** or **ESC** function button to exit a diagnostic session; Or
- 2. Tap the **Vehicle Swap** button on the new energy toolbar to return to the Vehicle Menu screen.
- 3. On the Vehicle Menu screen, tap the **Home** button in the top toolbar; or tap the **Back** button on the navigation bar at the bottom of the screen. Or
- 4. Tap the **Home** button on the toolbar to exit the application directly and return to the MaxiSys Job Menu.

## **NOTE**

After exiting the New Energy application, the tablet is no longer communicating with the vehicle and it is safe to open other MaxiSys applications.

# 5 Battery Pack Test

Using the Autel EVDiag Box, MaxiSys MS909EV is able to establish communication with the vehicle batteries to perform the Battery Pack Test function.

The battery pack data, including SOC/SOH, total voltage, total current, pack voltage delta, and temperature, can be viewed in this function. MaxiSys MS909EV supports the battery pack test of mainstream vehicles such as Tesla, BMW, GM, Audi, BYD, Honda, Toyota, Lexus, etc. The actual function menu may vary by vehicle.

## IMPORTANT

- This tablet must be operated only in accordance with local regulations and by properly qualified personnel. Only high voltage technicians and high voltage experts are allowed to perform high voltage related operations.
- Ensure that the battery pack has passed the insulation test. Before performing the test function, be sure to wear proper protective equipment, such as a helmet, protective suit, work shoes, and protective gloves.

# 5.1 Getting Started

## > To activate the Battery Pack Test function

1. Connect the main cable V2.0 to the Vehicle Data Connector on the VCI and tighten the thumb screws.



Figure 5-1 VCI Connecting to Main Cable V2.0

2. Connect the cable's 16-pin adapter to the OBDII connector of the EVDiag Box.



Figure 5-2 VCI Connecting to EVDiag Box

3. Power up the tablet. Ensure that the tablet battery has sufficient power.



Figure 5-3 Power up the Tablet

4. Connect the tablet with the VCI device and establish a communication link via Bluetooth, Wi-Fi or USB cable V2. See VCI Connection for more details.



Figure 5-4 Tablet Connecting to the VCI

5. Tap Battery Pack Test on the MaxiSys Job Menu.



Figure 5-5 Tap Battery Pack Test

6. Select the targeted manufacturer icon.



Figure 5-6 Main Screen on Vehicle Mode

7. Check the Technical Certification shown on the screen and tap OK to confirm.



Figure 5-7 Technical Certification Screen

## ⊘ NOTE

After the Technical Certification is confirmed, the Risk Warning and Disclaimer will pop up. Please read it carefully and tap **Accept** to continue.

- 8. Read the Safety Precautions shown on the screen and tap **OK** to confirm.
- 9. Select vehicle information accordingly.
- 10. Connect the EVDiag Box with a battery pack as per the on-screen diagram.

## **Connection Diagram:**



Figure 5-8 Adapter Connection Diagram



#### Figure 5-9 Breakout Lead Connection Diagram

## **⊘** NOTE

The required adapter or breakout leads may vary by vehicles. Please make the correct connection according to your actual situation.

11. Power up the EVDiag Box. Ensure the EVDiag Box is connected to the DC power supply. Tap OK on the tablet's Connection Diagram screen to connect the tablet with the EVDiag Box and establish a communication link. The Main Screen will appear once the link has been established.

## 

After the EVDiag Box is connected successfully, a green check will appear on the bottomright corner of the EVDB icon.



Figure 5-10 Main Menu on Vehicle Mode

# 5.2 Vehicle Mode

Tap the **Battery Pack Information** button on the Main Screen, the detailed battery pack data will be read and indicated automatically, such as SOC/SOH and module location. Besides, maintenance suggestions on the battery pack will be provided.

## 5.2.1 Battery Pack Information

- > To view the battery pack information
  - 1. Tap Battery Pack Information on the Main Menu (Figure 5-10).
  - 2. There are three items appear on the screen: Battery Pack Status, Battery Pack Information, and Other Live Data.



## Figure 5-11 Battery Pack Information Screen

3. Tap one of them to view the corresponding information.

# 6 Diagnostics

The Diagnostics application can access the electronic control module of multiple vehicle control systems, including but not limited to the engine, transmission, antilock brake system (ABS), and airbag system (SRS).

This tablet can not only perform professional diagnosis to new energy vehicles, but to fuel vehicles and hybrid vehicles. Before performing diagnostics function, refer to *Establish Vehicle Communication and Selection*. Connect the test vehicle with the tablet through the VCI device.

#### > To perform Diagnostics function

- 1. Establish a vehicle communication through VCI. See *Establish Vehicle Communication* for more details.
- 2. Identify the test vehicle by any of the vehicle identification ways supported by the tablet. See *Vehicle Identification* for more details.
- 3. Enter test system from Auto Scan or Control Unit screen.
- 4. Perform diagnosis on the left navigation bar.

The functions in the left navigation bar, such as Auto Scan, Control Unit, Service, Hot Functions, and Programming, are similar with those of the New Energy application. Refer to *New Energy* chapter for detailed operations.

# 6.1 Generic OBDII Operations

The OBDII/EOBD vehicle diagnosis option offers a quick way to check for DTCs, isolate the cause of an illuminated malfunction indicator lamp (MIL), check monitor status prior to emissions certification testing, and perform other emissions-related services. The OBDII direct access option is also used for testing OBDII/EOBD compliant vehicles that are not included in the database. Diagnostics Toolbar Buttons at the top of the screen are available for specific vehicle diagnostics. See *Table 4-2 New Energy Toolbar Buttons* for details.

## 6.1.1 General Procedure

#### > To access the OBDII/EOBD diagnostics functions

- 1. Tap the **Diagnostics** button from the MaxiSys Job Menu. The Vehicle Menu displays.
- 2. Tap the **EOBD** button. There are two options to establish communication with the vehicle.
  - Auto Scan select it to establish communication using each protocol in order to determine which one the vehicle is using.
  - Protocol select it to open a submenu of various protocols. A communication protocol is a standardized way of data communication between an ECM and a diagnostic tool. Global OBD may use several different communication protocols.
- Select a specific protocol if the **Protocol** option is selected. Wait for the OBDII/EOBD Diagnostic Menu to appear.





- 4. Select a function option to continue.
  - DTC & FFD
  - I/M Readiness
  - Live Data
  - O2 Sensor Monitor
  - On-Board Monitor
  - Component Test

- Vehicle Information
- Vehicle Status

## 

The supported functions may vary by vehicle.

## 6.1.2 Function Descriptions

This section describes the various functions of each diagnostic option:

## 6.1.2.1 DTC & FFD

When this function is selected, the screen displays a list of Stored Codes and Pending Codes. When the Freeze Frame data of certain DTCs are available for viewing, a snowflake button will display on the right side of the DTC item. The Erase Codes and Read codes functions can be applied by tapping the Function Buttons at the bottom of the screen.

## • Current Codes

Current codes are emission-related DTCs from the ECM of the vehicle. OBD II/EOBD Codes have a priority according to their emission severity, with higherpriority codes overwriting lower-priority ones. The priority of the code determines the illumination of the Malfunction Indicator Lamp (MIL) and the codes erase procedure. Manufacturers rank codes differently, so DTCs may vary by vehicle.

## • Pending Codes

These are codes whose storing conditions have been met during the last drive cycle, but need to be met on two or more consecutive drive cycles before the DTC stored. The purpose of displaying pending codes is to assist the service technician after a vehicle repair when diagnostic information is cleared, by reporting test results after a single driving cycle.

- a) If a test fails during the driving cycle, the DTC associated is reported. If the pending fault does not occur again within 40 to 80 warm-up cycles, the fault is automatically cleared from memory.
- b) Test results reported do not necessarily indicate a faulty component or system. If test results indicate another failure after additional driving, a DTC is stored to indicate a faulty component or system.

## • Freeze Frame

In most cases the stored frame is the last DTC reported. Certain DTCs, those that have a greater impact on vehicle emission, have a higher priority. In these cases,

DTC of the highest priority is the one for which the freeze frame records are retained. Freeze frame data includes a "snapshot" of critical parameter values at the time the DTC is stored.

#### • Erase Codes

This option is used to clear all emission-related diagnostic data including DTCs, freeze frame data and specific manufacturer-enhanced data from the vehicle ECM. This option resets the I/M Readiness Monitor Status for all vehicle monitors to Not Ready or Not Complete status.

A confirmation screen displays when the clear codes option is selected to prevent accidental loss of data. Select **Yes** on the confirmation screen to continue, or select **No** to exit.

#### 6.1.2.2 I/M Readiness

This function is used to check the readiness of the monitoring system. It is an excellent function to use prior to having a vehicle inspected for state emissions compliance. Selecting I/M Readiness opens a submenu with two choices:

- Since DTCs Cleared displays the status of monitors since the last time the DTCs are erased.
- This Driving Cycle displays the status of monitors since the beginning of the current drive cycle.

### 6.1.2.3 Live Data

This function enables the display of real-time PID data from the ECU. Displayed data includes analog and digital input and output, and system status information broadcast in the vehicle data stream.

Live data can be displayed in various modes, see *Live Data* for detailed information.

#### 6.1.2.4 O2 Sensor Monitor

This function allows retrieval and review of recent O2 sensor monitor test results stored on the vehicle's on-board computer.

The O2 Sensor Monitor test function is not supported by vehicles that communicate using a controller area network (CAN). For O2 Sensor Monitor tests results of CAN-equipped vehicles, refer to *On-Board Monitor*.

## 6.1.2.5 On-Board Monitor

This function allows you to view the results of On-Board Monitor tests. The tests are useful after the service when a vehicle's control module memory is already erased.

#### 6.1.2.6 Component Test

This function enables dual-directional control of the ECM so that the diagnostic tool can transmit control commands to operate the vehicle systems. This function is useful in determining how well the ECM responds to a command.

#### 6.1.2.7 Vehicle Information

This function enables the display of the vehicle identification number (VIN), calibration identification number, calibration verification number (CVN), and other information of the test vehicle.

#### 6.1.2.8 Vehicle Status

This function checks the current condition of the vehicle, such as the communication protocols of OBDII modules, number of fault codes, and status of the Malfunction Indicator Light (MIL).

# 7 Service

The Service section is specially designed to provide quick access to the vehicle systems for various scheduled service and maintenance tasks. The typical service operation screen is a series of menu driven executive commands. Follow on-screen instructions to select appropriate execution options, enter correct values or data, and perform necessary actions. The application will display detailed instructions to complete selected service operations.

After entering each special function, the screen will display two application choices: Diagnosis and Hot Functions. The Diagnosis enables the reading and clearing of codes which is sometimes necessary after completing certain special functions. Hot Functions consists of sub functions of the selected special function.

	Service					
Oil reset	ЕРВ	US TPMS	BMS			
Brake bleed	(CCC) Aftertreatment	Immo keys	Injector			
SAS	Suspension	Throttle	WIN DR ROOF			

Figure 7-1 Service Menu

Several most commonly used services are described in this chapter.

# 7.1 Oil Reset Service

Perform reset for the Engine Oil Life system, which calculates an optimal oil life change interval depending on the vehicle driving conditions and climate. The Oil Life Reminder must be reset each time the oil is changed, so the system can calculate when the next oil change is required.

## 🖉 ΝΟΤΕ

- 1. Always reset the engine oil life to 100% after every oil change.
- 2. All required work must be carried out before the service indicators are reset. Failure to do so may result in incorrect service values and cause DTCs to be stored by the relevant control module.
- For some vehicles, the scan tool can reset additional service lights such as maintenance cycle and service interval. On BMW vehicles for example, service resets include engine oil, spark plugs, front/rear brakes, coolant, particle filter, brake fluid, micro filter, vehicle inspection, exhaust emission inspection and vehicle checks.

# 7.2 Electric Parking Brake (EPB) Service

This function has a multitude of usages to maintain the electronic braking system safely and effectively. The applications include deactivating and activating the brake control system, assisting with brake fluid control, opening and closing brake pads, and setting brakes after disc or pad replacement.

## 7.2.1 EPB Safety

It can be dangerous to perform Electric Parking Brake (EPB) system maintenance, so before you begin the service work, please keep these rules in mind.

- ✓ Ensure that you are fully familiar with the braking system and its operation before commencing any work.
- ✓ The EPB control system may be required to be deactivated before carrying out any maintenance/diagnostic work on the brake system. This can be done from the tool menu.
- ✓ Only perform maintenance work when the vehicle is stationary and on level ground.
- ✓ Ensure that the EPB control system is reactivated after the maintenance work has been completed.

## Ø NOTE

Autel accepts no responsibility for any accident or injury arising from the maintenance of the Electric Parking Brake system.

# 7.3 Tire Pressure Monitoring System (TPMS) Service

This function allows you to quickly look up the tire sensor IDs from the vehicle ECU, as well as to perform TPMS replacement and reset procedures after tire sensors are replaced.

# 7.4 Battery Management System (BMS) Service

The Battery Management System (BMS) allows the tool to evaluate the battery charge state, monitor the close-circuit current, register the battery replacement, activate the rest state of the vehicle, and charge the battery via the diagnostic socket.

## **NOTE**

- 1. This function is not supported by all vehicles.
- 2. The sub functions and actual test screens of the BMS may vary by vehicle, please follow the on-screen instructions to make correct option selection.

The vehicle may use either a sealed lead-acid battery or an Absorbed Glass Mat (AGM) battery. Lead acid battery contains liquid sulphuric acid and can spill when overturned. AGM battery (known as VRLA battery, valve regulated lead acid) also contains sulphuric acid, but the acid is contained in glass mats between terminal plates.

It is recommended that the replacement aftermarket battery has the same specifications, such as capacity and type, as the exiting battery. If the original battery is replaced with a different type of battery (e.g. a lead-acid battery is replaced with an AGM battery) or a battery with a different capacity (mAh), the vehicle may require reprogramming of the new battery type, in addition to, performing the battery reset. Consult the vehicle manual for additional vehicle-specific information.

# 7.5 Diesel Particle Filter (DPF) Service

The Diesel Particle Filter (DPF) function manages DPF regeneration, DPF component replacement teach-in and DPF teach-in after replacing the engine control unit.

The ECM monitors driving style and selects a suitable time to employ regeneration. Cars driven a lot at idling speed and low load will attempt to regenerate earlier than cars driven more with higher load and speed. For regeneration to take place, a prolonged high exhaust temperature must be obtained.

In the event of the car being driven in such a way that regeneration is not possible, i.e., frequent short journeys, a diagnostic trouble code will eventually be registered in addition to the DPF light and "Check Engine" indicators displaying. A service regeneration can be requested in the workshop using the diagnostic tool.

Before performing a forced DPF regeneration using the tool, check the following items:

- The fuel light is not on.
- No DPF-relevant faults are stored in system.
- The vehicle has the specified engine oil.
- The oil for diesel is not contaminated.

## **U** IMPORTANT

Before diagnosing the problematic vehicle and attempting to perform an emergency regeneration, it is important to obtain a full diagnostic log and read out relevant measured value blocks.

## 

- 1. The DPF will not regenerate if the engine management light is on, or there is a faulty EGR valve.
- 2. The ECU must be re-adapted when replacing the DPF and when topping up the fuel additive Eolys.
- 3. If the vehicle needs to be driven in order to perform a DPF service, a second person is needed for the function. One person should drive the vehicle while the other person observes the screen on the Tool. Do not attempt to drive and observe the scan tool at the same time. This is dangerous and puts your life and the lives of other motors and pedestrians at risk.

# 7.6 Immobilizer (IMMO) Service

An immobilizer is an anti-theft mechanism that prevents an automobile's engine from starting unless the correct ignition key or other device is present. This device prevents thieves from starting the car by a method known as hot wiring. Most new vehicles have an immobilizer as standard equipment. An important advantage of this system is that it doesn't require the car owner to activate it; it operates automatically. An immobilizer is considered as providing much more effective anti-theft protection than an audible alarm alone; many auto insurance companies offer lower rates for vehicles that are equipped with an immobilizer.

As an anti-theft device, an immobilizer disables one of the systems needed to start a car's engine, usually the fuel supply or the ignition. This is accomplished by radio frequency identification between a transponder in the ignition key and a device called a radio frequency reader in the steering column. When the key is placed in the ignition, the transponder sends a signal with a unique identification code to the reader, which relays it to a receiver in the vehicle computer control module. If the code is correct, the computer allows the fuel supply and ignition systems to operate and start the car. If the code is incorrect or absent, the computer disables the system, and the car will be unable to start

until the correct key is placed in the ignition.

The IMMO service can disable a lost vehicle key and program the replacement key fob. One or more replacement key fobs can be programmed.

# 7.7 Steering Angle Sensor (SAS) Service

SAS Calibration permanently stores the current steering wheel position as the straightahead position in the SAS EEPROM. Therefore, the front wheels and the steering wheel must be set exactly to the straight-ahead position before calibration. In addition, the VIN is also read from the instrument cluster and stored permanently in the SAS EEPROM. On successful completion of calibration, the SAS fault memory is automatically cleared.

Calibration must always be carried out after the following operations:

- Steering wheel replacement
- SAS replacement
- Any maintenance that involves opening the connector hub from the SAS to the column
- Any maintenance or repair work on the steering linkage, steering gear or other related mechanism
- Wheel alignment or wheel track adjustment
- Accident repairs where damage to the SAS or assembly, or any part of the steering system may have occurred.

## 

- 1. Autel accepts no responsibility for any accident or injury arising from servicing the SAS system. When interpreting DTCs retrieved from the vehicle, always follow the manufacturer's recommendation for repair.
- All software screens shown in this manual are examples, and actual test screens may vary by test vehicle. Pay attention to the menu titles and onscreen instructions to make correct option selections.
- 3. Before starting procedure, make sure the vehicle has an ESC button. Look for button on dash.

# 8 ADAS

Advanced Driver Assistance Systems (ADAS) is an array of vehicle systems that aid the driver either through passive alerts or by active control of the vehicle to drive safer and with greater awareness and precision.

Cameras, sensors, ultrasound, radar and LIDAR are some of the systems used to capture the driving environment data, including travelling or static vehicles position, pedestrian location, road sign, driving lane and intersection detection, road (curves) and driving conditions (poor visibility or evening driving), use that information to instruct the vehicle to take its predetermined action. Cameras, sensors and sensing systems are typically located in front and rear bumpers, windshield, front grill and side and rearview mirrors.

Autel ADAS Calibration Tool provides comprehensive and precise ADAS calibration.

- 1. Covers many vehicle manufacturers, including Benz, BMW, Audi, Volkswagen, Porsche, Infiniti, Lexus, GM, Ford, Volvo, Toyota, Nissan, Honda, Hyundai, and Kia.
- Supports the calibration of multiple driver assistant systems, including Adaptive. Cruise Control (ACC), Night Vision System (NVS), Lane Departure Warning (LDW), Blind Spot Detection (BSD), Around View Monitoring (AVM), Rear Collision Warning (RCW), and Heads-up Displays (HUD).
- 3. Supplies graphic illustrations and step-by-step instructions.
- 4. Provides demos to guide the technician through the calibration.



Figure 8-1 ADAS Introduction Screen

# **9** Data Manager

The Data Manager application allows you to store, print, and review the saved files, manage the workshop information, and customer information records, and keep test vehicle history records.

Selecting the Data Manager application opens the file system menu. There are nine main functions available.



## Figure 9-1 Data Manager Main Screen

The table below briefly describes each of the function buttons in the Data Manager application.

i abie	9-1	Buttons	in Da	ta IV	ianag	er

Button	Name	Description				
F	Vehicle History	Tap to review the diagnostics history record.				

Button	Name	Description
Â	Workshop Information	Tap to edit the information of workshops.
2	Customer	Tap to create new customer information.
	Image	Tap to review the screenshots.
	Cloud Report	Tap to review the saved reports and share cloud reports.
PDE	PDF	Tap to review the reports stored as PDF files.
	Review Data	Tap to review the recorded data.
E	Data Logging	Tap to review the communication data and ECU information of the vehicle. The saved data can be reported and sent to the technical center via the Internet.
B	Uninstall Apps	Tap to uninstall applications.

# 9.1 Vehicle History

This function stores records of test vehicle history, including vehicle information and the retrieved DTCs from previous diagnostic sessions. Test information is summarized and displayed in an easy-to-read table listing. The Vehicle History also provides direct access to the previously tested vehicle and allows you to directly restart a diagnostic session without needing to perform auto or manual vehicle selection.

(1)	New	Energy Battery Pack Test Diagnostics	s Service Battery Test Demonstration	۹ /
$\smile$	2022.7			3 Records
	2019_05 BMW 5'/530Le iPerformance_B48	2021_01 BMW X'/iX3	2021_01 BMW X'/iX3	
	2022-07-25 15:21:25 BMW/2019_05/5/530Le iPerf_	2022-07-11 16:16:27 BMW/2021_01/X/X3	2022-07-01 09:51:23 BMW/2021_01/X/X3	
	DTC Count:0	DTC Count:0	DTC Count:0	
	VIN: LBVKY9104KSR97772	VIN: LBV7X4109MSZ59663	VIN: LBV7X4109MSZ59663	
	<b>@</b>	<b>@</b>	<b>(</b>	
	2022.6			17 Records
(2)	2022.5			24 Records
•	2022.4			2 Records

### Figure 9-2 Vehicle History Screen

- 1. Top Toolbar Buttons navigation and application controls.
- 2. Main Section displays all the vehicle history records.
- > To activate a test session for the recorded vehicle
  - 1. Tap Data Manager on the MaxiSys Job Menu.
  - Select Vehicle History to open the screen. Tap the relevant application tab to select the test record. For example, tap New Energy to select diagnostics test records.
  - 3. Tap the **New Energy** icon at the bottom of the thumbnail of a vehicle record item.
  - 4. The New Energy screen of the vehicle displays and a new diagnostics session is activated. See *New Energy* to continue the diagnostics. Or,
  - Select a vehicle thumbnail to open a record. A Historical Test record sheet displays. Review the recorded information of the test vehicle, and tap the New Energy button on the upper-right corner.

## 🖉 ΝΟΤΕ

The MaxiSys tablet must establish a stable connection to the VCI device to restart test sessions on the previously tested vehicles.

## 9.1.1 Historical Test Record

The Historical Test Record is a detailed data form of the vehicle, which includes general vehicle information, service record, customer information, and the diagnostic trouble codes retrieved from the previous test sessions. Technician Notes will also appear if present.

-		Historical Test		1
Title	Aston Martin Cygnet (As of 201	View PDF		
Vehicle Inforn	nation			🖶 Print
Year		License plat	e	E-mail
Make	Aston Martin	VIN		Get Report
Model	Cygnet (As of 2011)	Odometer		Get Report
Sub model		Color	Color	Delete
Engine		Status	Not started	
Service record	i			
Technician				
Technician Notes				A
Customer info	ormation			

#### Figure 9-3 Historical Test Record Sheet

#### > To edit the Historical Test record

- 1. Tap Data Manager on the MaxiSys Job Menu.
- 2. Select Vehicle History.
- 3. Select the specific vehicle history record thumbnail from the main section. The Historical Test record will display.
- 4. Tap Edit (a pen icon) to start editing.
- 5. Tap each item to input information or attach files or images.

## NOTE

The vehicle VIN, license number, and customer account information are correlated by default. Vehicle records will automatically be correlated using this vehicle and customer identification.

- Tap Add to Customer to correlate the Historical Test record sheet to an existing customer account, or add a new associated account to be correlated with the test vehicle record. See *Customer* for more information.
- 7. Tap Done to save the updated record, or tap Cancel to exit without saving.

# 9.2 Workshop Information

The Workshop Information form allows you to edit, input, and save the detailed workshop information, such as shop name, address, phone number, and other remarks, which, when printing vehicle diagnostic reports and other associated test file, will display as the header of the printed documents.

-		Workshop information	
Basic information			
	Set shop logo		Logo
Shop name		Tel	
State		Fax	
City		E-mail	
Zip code			
Address			
More information			
Manager name		Manager title	
Website			
Slogan			

#### Figure 9-4 Workshop Information Sheet

#### > To edit the Workshop Information sheet

- 1. Tap the **Data Manager** application on the MaxiSys Job Menu.
- 2. Select Workshop Information.
- 3. Tap on each field to input the appropriate information.
- 4. Tap **Done** to save the updated workshop information record, or tap **Cancel** to exit without saving.

## 9.3 Customer

The Customer function allows you to create and edit customer accounts. It helps you to save and organize all customer information accounts that are correlated with the associated test vehicle history records.

- > To create a customer account
  - 1. Tap the Data Manager application on the MaxiSys Job Menu.
  - 2. Select Customer.

3. Tap the **Add a Customer** button. An empty information form displays; tap each field to input the appropriate information.

## Ø NOTE

The items that must be filled are indicated as required fields.

- 4. Some customers may have more than one vehicle for service; you can always add new vehicle information to the account. Tap **Add New Vehicle Information**, and then fill in the vehicle information. Tap the <sup>③</sup> button to cancel.
- 5. Tap **Complete** to save the account, or tap **Cancel** to exit without saving.

#### > To edit a customer account

- 1. Tap Data Manager on the MaxiSys Job Menu.
- 2. Select Customer.
- 3. Select a customer account by tapping the corresponding name card. A Customer Information record displays.
- 4. Tap the **Edit** icon on the top toolbar to start editing.
- 5. Tap on the input field to edit or amend information, and enter the updated information.
- 6. Tap **Complete** to save the updated information, or tap **Cancel** to exit without saving.

#### > To delete a customer account

- 1. Tap Data Manager on the MaxiSys Job Menu.
- 2. Select Customer.
- 3. Tap the **Delete** icon on the right of a customer account. A message displays.
- 4. Tap **OK** to confirm the command, and the account is deleted, or tap **Cancel** to cancel the request.

# 9.4 Image

The Image section is a PNG database containing all captured screenshots.



## Figure 9-5 Image Database Screen

- 1. Toolbar Buttons used to edit, print, or delete the image files. See *Table 9-2 Toolbar Buttons in PNG Database* for detailed information.
- 2. Main Section displays the stored images.

Table 9-2	Toolbar	<b>Buttons</b>	in PNG	Database
-----------	---------	----------------	--------	----------

Button	Name	Description
ŧ	Back	Returns to the previous screen.
Q	Search	Tap to search the image by entering its stored time.
	Edit	Tap to display the editing toolbar to select, delete, print, or email the image(s).
Cancel	Cancel	Tap to close the editing toolbar or cancel file search.
Ĩ	Print	Tap to print the selected image.
	Delete	Tap to delete the selected image.

Button	Name	Description
X	Email	Tap to send the selected image to an email.

#### > To edit/delete image(s)

- 1. Select **Data Manager** from the MaxiSys Job Menu.
- 2. Select Image to access the PNG database.
- 3. Tap Edit on the top-right corner of the window. The editing screen displays.
- 4. Select the image(s) you want to edit by tapping the check box at the bottomright corner of the image.
- Tap the **Delete** icon to delete the selected images or delete all images. Tap the **Print** icon to print the selected image(s). Tap the **Email** icon to send the selected image(s) to an email.

# 9.5 Cloud Report

This section displays the saved reports, which can be transferred to the Autel cloud platform once a stable network connection is established. These reports can then be viewed or shared with others. See *Report Settings* and *Diagnostics Report Saving*, *Viewing*, and Sharing for further details.

# 9.6 PDF Files

The PDF files designated for local viewing are displayed in this section. Enter the PDF database and select a file to access the saved information.

This section uses the standard Adobe Reader application for file viewing and editing. Please refer to the associated Adobe Reader manual for more detailed instructions.

## 9.7 Review Data

The Review Data section allows you to play back the recorded data frames of live data streams.

On the Review Data main screen, select a record file to play back.

Absolute Load Value  Actual exhaust (B) camshaft position (bank 1)  Engine speed  Relative accelerator pedal position	15 37.25 3685.75	% Deg rpm
Engine speed O	3685.75	-
		rpm
Relative accelerator pedal position		
-	10	%

Figure 9-6 Data Playback Screen

- 1. Main Section displays the recorded data frames.
- 2. Navigation Toolbar allows you to manipulate data playback.

Use the Navigation Toolbar buttons to play back the record data from frame to frame.

Tap **Back** to exit data playback.

## 9.8 Data Logging

The Data Logging section allows you to launch Support platform directly to view all records of all feedback or no feedback data loggings on the diagnostic system. For more details, see *Data Logging*.

# 9.9 Uninstall Apps

This section allows you to manage the software applications installed on the MaxiSys diagnostics system. Selecting this section opens a managing screen, on which you can check all available vehicle diagnostic applications.

Select the vehicle software you want to delete by tapping on the vehicle manufacturer icon. The selected item will display a blue mark at the upper-right corner. Tap the **Delete** button on the top toolbar to delete the software from the system database.

# **10** Battery Test

The Battery Test application allows the user to perform in-vehicle battery test and outvehicle battery test functions when the BT506 battery tester is connected to the MaxiSys tablet and a battery. The BT506 battery tester enables technicians to view the health status of the vehicle's battery and electrical system.

## 

The BT506 battery tester needs to be purchased separately.



Figure 10-1 Battery Test Screen

# 10.1 MaxiBAS BT506 Battery Tester

## **10.1.1 Function Description**



Figure 10-2 MaxiBAS BT506 Tester

- 1. Power Button
- 2. Status LED
- 3. Power LED
- 4. USB Port
- 5. Battery Clamp Cable

### Table 10-1 LED Description

LED	Color	Description
	Flashing Green	The tester is communicating via USB cable.
Status LED	Flashing Blue	The tester is communicating via Bluetooth.
	Flashing Red	Battery clamps are connected to the wrong battery terminals.

LED	Color	Description
	Solid Green	The tester is powered on and the battery is sufficiently charged.
Power LED	Flashing Green	The tester is charging. (Turns solid green when battery is fully charged.)
	Solid Red	The device is in boot mode.
	Flashing Red	The battery level is low. Please charge.

## 10.1.2 Power Sources

The MaxiBAS BT506 tester can receive power from the following sources:

- Internal Battery Pack
- AC/DC Power Supply

### **IMPORTANT**

Do not charge the tester when the temperature is below 0 °C (32 °F) or above 45 °C (113 °F).

10.1.2.1 Internal Battery Pack

The MaxiBAS BT506 battery tester can be powered with the internal rechargeable battery.

10.1.2.2 AC/DC Power Supply — Using Power Adapter

The MaxiBAS BT506 battery tester can be powered from an electrical outlet using the AC/DC power adapter. The AC/DC power supply also charges the internal battery pack.

## **10.1.3 Technical Specifications**

#### Table 10-2 Technical specifications

Item	Description
Connectivity	<ul><li>USB 2.0, Type C</li><li>Bluetooth 4.2</li></ul>
Input Voltage	5 V DC
Working Current	< 150 mA at 12 V DC
Item	Description
-----------------------	---
Internal Battery	3.7 V/800 mAh Lithium-ion Polymer battery
CCA Range	100 to 2000 A
Voltage Range	1.5 to 16 V
Working Temp.	- 10 °C to 50 °C (14 °F to 122 °F)
Storage Temp.	- 20 °C to 60 °C ( - 4 °F to 140 °F)
Dimension (L x W x H)	107 mm (4.21") x 75 mm (2.95") x 26 mm (1.02") (clamp cable not included)
Weight	320 g (0.7 lbs.)

## **10.2 Test Preparation**

## 10.2.1 Inspect the Battery

Before starting a test, inspect the battery for:

- Cracking, buckling or leaking. If you see any of these defects, replace the battery.
- Corroded, loosen or damaged cables and connections. Repair or replace as needed.
- Corrosion on the battery terminals, and dirt or acid on the case top. Clean the case and terminals using a wire brush and a mixture of water and baking soda.

## 10.2.2 Connect the Battery Tester

#### > To pair with the MaxiSys tablet

- 1. Turn on both the MaxiSys tablet and the BT506 battery tester. Ensure that the units are sufficiently charged before you begin.
- Enable Bluetooth on the tablet by tapping VCI Manager > BAS BT. Tap Scan at the top-right corner. The device will start to search for available pairing units.
- Depending on the type of battery tester, the device name may display as "Maxi" suffixed with a serial number. Select the appropriate device for pairing.
- 4. When paired successfully, the connection status will read "Connected."



Figure 10-3 Battery Tester Connection Example 1

- ≻ To connect to a battery
  - 1. Connect the red clamp to the positive (+) terminal of the battery.
  - 2. Connect the black clamp to the negative (-) terminal of the battery.



Figure 10-4 Battery Tester Connection Example 2

## 10.3 In-vehicle Test

The In-vehicle Test is used for testing batteries that are installed in a vehicle. An in-vehicle test includes the Battery Test, Starter Test, and Generator Test. These tests help determine the health of the battery, the starter, and the generator.

### IMPORTANT

A disclaimer will appear when first accessing any function on the Home screen. Please read the end-user agreement and tap Accept to continue. If you tap Decline, you will not be able to use the features properly.

Prior to testing any battery, ensure that the battery tester is paired with the tablet via Bluetooth and connected properly to a battery.

#### > To start the in-vehicle test

- 1. Tap Battery Test on the MaxiSys Job Menu. Select In-vehicle Test.
- 2. Confirm the vehicle information on the left side of the screen. Make sure the VIN is entered.
- 3. Confirm your battery information, including voltage, type, standard, and capacity. Tap **Next** to continue in-vehicle test functions.

Vehicl	e information		13.1
License	Туре	Standard	Capacity
* VIN	Type	Standard	Capacity
<ul> <li>▼ (⊕)</li> </ul>			
Make			
Citroen >	FLOODED	CCA	1050
Year			
ALL >			
Model			
C-ELYSEE >			
Others			
None >			
		Bat	tery Next

Figure 10-5 Battery information Screen

### NOTE

In the Settings application, the Battery Test option allows you to change the requirement for entering the VIN information. If the setting is enabled, supplying the VIN is no longer mandatory.

Refer to the table below for a list of buttons that may appear when accessing the functions:

#### Table 10-3 Top Toolbar Buttons

Button	Name	Description
12.3	Battery Connection	The value on the icon indicates the real-time voltage of the tested battery. In the battery test, the button will turn green if the battery is good; otherwise, it will turn red.

Button	Name	Description
Next	Next	Tap to proceed.
	Home	Returns to the battery test main screen.
	Back	Returns to the previous screen.
•	Exit	Returns to the Job Menu.

## 10.3.1 Battery Test

1. Follow the on-screen instructions. Check the boxes once all required tasks are completed, and tap **Start Testing**.



Figure 10-6 Battery Screen

2. Wait until the test is completed. The test results will be displayed on the tool.

🗢 🕞 Battery	Starter Generator		
	Good Batter		
	SOC	100	6
	Voltage	13.1	2 V
	Measured	1066	5 CCA
	Capacity	1050	O CCA
	Temperature	31 °	c
		Report	Continue

Figure 10-7 Battery Test Results Screen

## Table 10-4 Test Results

Result	Description
Good Battery	Battery is good.
Good & Recharge	Battery is good but insufficiently charged. Recharge the battery.
Charge & Retest	Battery requires charge to determine its condition.
Bad Cell	Replace the battery.
Replace Battery	Replace the battery.

## ⊘ NOTE

Please always complete the battery test before you proceed to the starter and generator tests.

## 10.3.2 Starter Test

Follow the on-screen instructions to complete the test. Start the engine and let it idle. The test results will appear as follows:

<ul> <li>•</li> </ul>	Battery	Starter	Generator	
			Cranking norma	l.
		Starting voltage		11.99 V 💙
	\	Starting time		0.57 S
				Report Continue

### Figure 10-8 Starter Test Result Screen

#### Table 10-5 Starter Test Results

Result	Description	
Cranking Normal	The starter is good.	
Current Too Low	Low momentary discharge capacity.	
Voltage Too Low	Low battery storage capacity.	
Not Started	The starter is not detected for starting.	

## 10.3.3 Generator Test

Follow the on-screen instructions to complete the test. The test results will appear as follows:



### Figure 10-9 Generator Test Results Screen

Result	Description	
Charging Normal	The generator is functioning normally.	
Output Too Low	<ul> <li>The belt linking the starter and the generator is loose;</li> <li>The cable linking the starter and battery is loose or corroded.</li> </ul>	
Output Too High	<ul> <li>The generator is not properly connected to the ground;</li> <li>The voltage adjuster is broken and needs replacement.</li> </ul>	
Ripple Too Large	The commutation diode is broken.	
No Output	<ul> <li>The cable is loose;</li> <li>Some vehicles with power management systems do not provide path for charging due to the sufficient load capacity of the battery;</li> <li>The generator or the voltage adjuster is broken and needs replacement.</li> </ul>	

#### Table 10-6 Generator Test Results

## 10.4 Out-vehicle Test

Out-vehicle Test is used to test the condition of batteries that are not connected to a vehicle. This function aims to check the health status of the battery only.

## 10.4.1 Test Procedure

- > To start the out-vehicle test
  - 1. Connect the tester clamps to the battery terminals.
  - 2. Tap Battery Test on the MaxiSys Job Menu. Select Out-vehicle Test.
  - 3. Select the appropriate battery type, rating standard, and CCA value. Tap **Start Testing** to start the test.

	Out-vehicle test			13.0
	Battery voltage		_	
		12V	•	
	Туре	Standard	Capacity	
4				
	FLOODED	CCA	1050	
Battery test is ready. Press Start Testing				
	Check if the battery in	formation is correct.		Start

Figure 10-10 Out-vehicle Test Screen

4. The test results will display in a few seconds.

	Out-vehicle test	
	Good Battery	
	SOH 100%	
4 📀	SOC	100%
	Voltage	13.07 V
Good Battery	Measured	1065 CCA
	Capacity	1050 CCA
	Temperature	31 °C
		Report

Figure 10-11 Out-vehicle Test Results Screen

## 10.4.2 Test Results

Result	Description
Good Battery	Battery meets required standards.
Good & Recharge	Battery is good, but low on charge. Fully charge the battery. Check for causes of low charge.
Charge & Retest	Battery requires charge to determine its condition.
Replace Battery	Battery fails to meet industry-accepted standards.
Bad Cell	Battery fails to meet industry-accepted standards.

#### Table 10-7 Out-Vehicle Test Results

## **11** Update

The Update application on the tablet downloads the latest version of the software. The updates improve the MaxiSys applications' capabilities, typically by adding new tests, new model coverage or by adding new or enhanced applications.

The tablet automatically searches for available updates for all of the MaxiSys software when it is connected to the Internet. Any updates that are found can be downloaded and installed on the device. This section describes update procedures in the MaxiSys system.

### **NOTE**

Ensure the tablet is registered before utilizing the Update application. See *Autel User Center* for a comprehensive registration guide.

#### > To update the software

- 1. Power up the tablet, and ensure that it is connected to a power source and has a steady Internet connection.
- 2. Tap the **Update** application button from the MaxiSys Job Menu. The Update application screen displays.
- 3. On the Update screen, tap the **Get** button to update the specific item(s) or tap the **Update All** button to update all available items.
- 4. Tap **More** to view the details of all the available updates. You can also tap the **Get** or **Update All** button for update.
- During the update, tap the <sup>●</sup> icon to suspend the updating process. Tap the
   icon to resume the update and the process will continue from the pause point.
- 6. When the updating process is completed, the software will be installed automatically. The new version will replace the older version.

## 🖉 NOTE

For the account management, proceed to the Member Center tab.

## **12** Settings

Access the Settings menu to adjust default setting and view information about the MaxiSys system. The following options are available for the MaxiSys system settings:

- Unit
- Language
- Printing Settings
- Report Settings
- Push Notification
- Auto Update
- ADAS Settings
- Vehicle List
- EVDiag Box Settings
- AutoVID Setup
- Country/Region Code
- System Settings
- About

## 12.1 Unit

This option allows you to change the measurement unit for the diagnostic system.

- > To adjust the unit setting
  - 1. Tap the **Settings** application on the MaxiSys Job Menu.
  - 2. Tap the Unit option on the left column.
  - 3. Select the appropriate measurement unit. A check mark will display to the right of the selected unit.
  - 4. Tap the **Home** button on the top-left corner to return to the MaxiSys Job Menu, or select another settings option for system setup.

## 12.2 Language

This option allows you to adjust the display language for the MaxiSys system.

### > To adjust the language setting

- 1. Tap the **Settings** application on the MaxiSys Job Menu.
- 2. Tap the Language option on the left column.
- 3. Select the appropriate language. A check mark will display to the right of the selected language.
- 4. Tap the **Home** button on the top-left corner to return to the MaxiSys Job Menu, or select another settings option for system setup.

## 12.3 Print Settings

This option allows you to print from the tablet to a network printer via a computer.

### > To setup the printer connection

- 1. Tap **Settings** on the MaxiSys Job Menu.
- 2. Tap **Printing Settings** on the left column.
- 3. Tap **Print via PC-link** or **Print via Wi-Fi** to activate the printing function, which enables the device to send files to the printer through the PC via Wi-Fi or Ethernet connection.
- 4. Tap the **Home** button on the top-left corner to return to the MaxiSys Job Menu, or select another settings option for system setup.

## 12.3.1 Printing Operations

### > To install the MaxiSys Printer driver

- Download Maxi PC Suite from <u>www.autel.com</u> > Support > Downloads > Autel Update Tools, and install it to a Windows-based PC.
- 2. Double click on **Setup.exe**.
- 3. Select the installation language and the wizard will load.
- 4. Follow the instructions on the screen and Click on **Next** to continue.
- 5. Click Install and the printer driver program will be installed onto the computer.
- 6. Click **Finish** to complete the installation.

## 🖉 NOTE

The MaxiSys printer runs automatically after the installation. The PC, printer and the tablet must be connected to the same network.

This section describes how to receive file from the MaxiSys tablet and perform printing through the PC.

## 🖉 NOTE

- Make sure the tablet is connected to the same network with your computer, either via Wi-Fi or LAN, before printing.
- Make sure the computer installed with the Printing Services program is connected to a printer.
- > To perform printing through the computer
  - 1. Ensure the tablet is connected to the computer network, either via Wi-Fi or LAN, before printing.
  - 2. Run the PC Link program on the computer.
  - 3. Select the MaxiSys Printer tab.
  - 4. Tap the **Print** button in the tablet top toolbar. A document will be sent to the computer.
    - If the **Auto Print** option in the MaxiSys Printer is selected, the MaxiSys Printer will print the received document automatically.
    - If the Auto Print option is not selected, click Open PDF File button to view files. Select the file(s) to print and click Print.

## 🖉 NOTE

To confirm that the printer is functioning normally, you can click **Test Print** in the PC Link program to test.

## 12.4 Report Settings

Toggle the **ON/OFF** button to enable/disable Report Upload to Cloud function. If the button displays blue, it indicates the Report Upload to Cloud function is enabled. If the button displays gray, it indicates the Report Upload to Cloud function is disabled.

## **12.5 Push Notification**

This option allows you to manage notifications. The Notification Preference is turned on by default and cannot be turned off by users so that certain system notifications such as system security warnings won't be blocked. Internet access is required for receiving online messages.

#### > To manage other notifications

- 1. Tap **Settings** on the MaxiSys Job Menu.
- 2. Tap Push Notifications on the left column.
- 3. Tap the 👻 button on the right to open a drop-down list.
- 4. There are four options: Enable all notifications, Limit to 3 notifications or less per week, Limit to 1 notification per week, and Disable all notifications. Select whichever you want.
- 5. Tap **Home** on the top-left corner to return to the MaxiSys Job Menu. Or select another settings option for the system setup.

## **NOTE**

- Notifications will display on the screen. Slide the screen from top to check the received messages. If the message list covers more than one screen, slide the list up or down to view them.
- Tapping a specific message launches the corresponding application. For example, if you tap on an Update notification, the Update application will be launched.

## 12.6 Auto Update

The Auto Update allows the tool to automatically update the OS, the MaxiSys system, and the vehicle coverage software. Each can be configured to update automatically at a specified time. Tap the **ON/OFF** button to enable/disable the desired automatic update time.

#### > To set auto system or vehicle update

- 1. Tap the **Settings** application on the MaxiSys Job Menu.
- 2. Tap the **Auto Update** option on the left column. The three auto update items will display on the right of the screen.
- 3. Select the update type to schedule. Toggle the button to **ON**.
- 4. Tap on the time to set the time of the day for updating. If the update time is set and the device is connected to the Internet, the selected software will be automatically updated at the configured time.

## 12.7 ADAS Settings

- > To activate the MaxiSys ADAS calibration
  - 1. Confirm the registered MaxiSys tablet has available updates.
  - 2. Select **Settings** on the MaxiSys Job Menu.
  - 3. Tap on ADAS Settings.

- 4. Scan the QR code on the ADAS frame to bind, or manually input frame serial number when QR code is not available.
- 5. Enter the validation code from the ADAS Calibration Card.
- 6. The system will be reset and the Job Menu will display once the registration has been completed.

## 12.8 Vehicle List

This option allows you to sort the vehicles either by alphabetic order or by frequency of use.

### > To adjust the vehicle list setting

- 1. Tap the **Settings** application on the MaxiSys Job Menu.
- 2. Tap Vehicle List on the left column.
- 3. Select the required sort type. A check mark will display to the right of the selected item.
- 4. Tap the **Home** button in the top-left corner to return to the MaxiSys Job Menu, or select another settings option for system setup.

## 12.9 EVDiag Box Settings

When the EVDiag Box device is linked with the tablet, this MaxiSys diagnostics system can support the battery pack test function.

#### > To link the EVDiag Box device

- 1. Tap the **Settings** application on the MaxiSys Job Menu.
- 2. Tap the EVDiag Box Settings option on the left column.
- 3. Connect the EVDiag Box according to the on-screen connection diagram.
- 4. Tap **Read** to automatically acquire the EVDiag Box serial number and tap **Link EVDiag Box**.
- 5. Restart your tablet to automatically download the Battery Pack Test software.

## 12.10 AutoVID Setup

This option allows you to enable/disable the automatic vehicle VIN reading function. When this function is active, the tablet will read the vehicle VIN via the communication methods you enabled after the VCI is connected to the vehicle.

## 12.11 Country/Region Code

This function provides Wi-Fi channel options for different country regions to ensure reliable and stable Wi-Fi communication. Please connect the tablet with VCI device before making adjustment.

### > To adjust the country code setting

- 1. Tap the **Settings** application on the MaxiSys Job Menu.
- 2. Tap the Country/Region Code option on the left column.
- 3. Select the appropriate country/region. A confirmation message will display.
- 4. Tap the **Home** button on the top-left corner to return to the MaxiSys Job Menu, or select another settings option for the system setup.

## **NOTE**

If the tablet cannot find the VCI device via Wi-Fi connection after setting the country code, please connect the VCI with tablet via USB cable or Bluetooth connection to retry.

## 12.12 System Settings

This function provides you with direct access to the Android system setting interface, where you can adjust various system settings for the Android system platform. Regarding wireless and networks settings, various device settings such as sound and display, as well as system security settings, and check related information about the Android system. Refer to Android documentation for additional information.

## 12.13 About

The About function provides information of the MaxiSys diagnostic device including the product name, version, hardware, and serial number.

- > To check the MaxiSys product information in About
  - 1. Tap the **Settings** application on the MaxiSys Job Menu.
  - 2. Tap the **About** option on the left column. The product information screen displays on the right.
  - 3. Tap the **Home** button on the top-left corner to return to the MaxiSys Job Menu, or select another settings option for system setup.

## 13 VCI Manager

The VCI Manager is an application for connecting the MaxiSys tablet with VCI device. This application allows you to pair the tablet with the VCI and to check the communication status. You can either build the connection via the Bluetooth or Wi-Fi, of which the latter is more stable and faster in speed for module operation.



Figure 13-1 VCI Manager Screen

- 1. **Connection Mode**: five connection modes are available. The connection status displays adjacent to each mode.
  - Wi-Fi Connection when connected to a wireless device, the connection state displays as "Connected." Otherwise, it displays as "Disconnected."
  - VCI Bluetooth Pairing when the VCI is paired to the tablet via Bluetooth, the connection status displays as "Connected." Otherwise, it displays as "Disconnected."
  - BAS Bluetooth Pairing— when paired to a battery tester via Bluetooth, the connection status displays as "Connected." Otherwise, it displays as "Disconnected."
  - VCI Update connects the VCI to the MaxiSys tablet, then updates the VCI firmware through the tablet.
  - BAS Update connects the battery tester to the MaxiSys tablet, then updates the battery tester's firmware through the tablet.

 Settings: this section allows you to manage wireless pairing or set up network connection. Toggle the ON/OFF button to ON. The available devices for pairing will display. Tap the needed one to start pairing.

## 13.1 Wi-Fi Connection

Wi-Fi Connection is an advanced function for quick linkage with VCI. Since Wi-Fi connection supports 5G, the MaxiSys tablet and VCI device share a faster and more stable connection when using this communication method. The tablet can be operated up to 50 meters away from the VCI device when connected to the vehicle.

#### > To connect the VCI to the tablet via Wi-Fi

- 1. Power on the tablet.
- 2. Connect the 26-pin end of the main cable to the VCI's vehicle data connector.
- Connect the 16-pin end of the main cable to the vehicle data link connector (DLC).
- 4. Tap VCI Manager on the MaxiSys Job Menu of the tablet.
- 5. Select Wi-Fi from the connection mode list.
- 6. Swipe the Wi-Fi toggle button to **ON**. Tap **Refresh** at the top-right corner. The device will start to search for available units.
- 7. Depending on the VCI type you use, the device name may display as "Maxi" suffixed with a serial number. Select the appropriate device for connection.
- 8. When the connection is established, the connection status displays as "Connected".
- 9. The VCI button on the system navigation bar at the bottom of the screen displays a green Wi-Fi icon, indicating the tablet is connected to the VCI device.
- 10. Tap the connected device again to disconnect the device.
- 11. Tap **Back** on the top-left corner to return to the MaxiSys Job Menu.

### **NOTE**

To ensure a quick connection, please connect in a steady network environment.

## 13.2 VCI Bluetooth Pairing

Bluetooth Paring is the basic way for wireless connection. The VCI device needs to be either connected to a vehicle or to an available power source, so that it is powered up during the synchronization procedure. Make sure the tablet has a charged battery or is connected to an AC/DC power supply.

### > To pair the VCI device with the tablet

- 1. Power on the tablet.
- 2. Connect the 26-pin end of the main cable to the VCI's vehicle data connector.
- Connect the 16-pin end of the main cable to the vehicle data link connector (DLC).
- 4. Tap VCI Manager on the MaxiSys Job Menu of the tablet.
- 5. Select VCI BT from the connection mode list.
- 6. Swipe the Bluetooth toggle button to **ON**. Tap **Scan** at the top-right corner. The device will start to search for available pairing units.
- 7. Depending on the VCI type you use, the device name may display as "Maxi" suffixed with a serial number. Select the appropriate device for pairing.
- 8. When paired successfully, the connection status displays as "Connected."
- 9. Wait a few seconds, and the VCI button on the system navigation bar at the bottom of the screen will display a green BT icon, indicating the tablet is connected to the VCI device.
- 10. Tap the connected device again to disconnect the device.
- 11. Tap **Back** on the top left to return to the MaxiSys Job Menu.

## **NOTE**

A VCI device can be paired to only one tablet at a time, and once it's been paired, the device will not be discoverable for any other unit.

## 13.3 BAS Bluetooth Pairing

The BT506 battery tester device can be connected with the tablet via Bluetooth. Ensure that the BT506 battery tester is sufficiently charged or is connected to the external power supply before use.

### > To pair the Battery Tester with the tablet

- 1. Power on the tablet and the battery tester.
- 2. Tap VCI Manager on the MaxiSys Job Menu of the tablet.
- 3. Select **BAS BT** from the connection mode list.
- 4. Swipe the Bluetooth toggle button to **ON**. Tap **Scan** at the top-right corner of the screen. The device will start to search for available units to pair with.
- Depending on the type of battery tester, the device name may appear as "Maxi" suffixed with the battery test's serial number. Select the appropriate device for pairing.
- 6. When paired successfully, the connection status reads "Connected."

## 13.4 VCI Update

VCI Update provides the latest update for the connected VCI device. Before updating the VCI firmware, make sure the tablet network is stable, and do not leave the VCI Update page during upgrade.

#### > To update the VCI firmware

- 1. Power on the tablet.
- 2. Connect the VCI device to the tablet via USB cable.
- 3. Tap VCI Manager on the MaxiSys Job Menu of the tablet.
- 4. Select VCI Update from the connection mode list.
- 5. If the installed version is not the latest one, the current version and the latest version will display on the screen after a few seconds. Tap **Update Now** to update the VCI firmware if available.

## 13.5 BAS Update

Before updating the battery tester firmware, please make sure the network connection is stable.

#### > To update the battery tester firmware

- 1. Power on the tablet and the battery tester.
- 2. Connect the battery tester to the tablet via Bluetooth or USB cable.
- 3. Tap the VCI Manager application on the MaxiSys Job Menu of the tablet.
- 4. Select **BAS Update** from the connection mode list.
- 5. If the installed version is not the latest one, the current version and the latest version will display on the screen after a few seconds. Tap **Update Now** to update the BAS firmware if available.

## 

Do not leave the BAS Update page during upgrade.

## **14** Support

This application launches the Support platform which synchronizes Autel's online service base station with the MaxiSys tablet. Connected to Autel's service channel and online communities, the Support application provides the quickest way for problem solutions, allowing you to send help requests to obtain direct service and support.

## 14.1 Support Screen Layout

The Support application interface is navigated by the Home button on the top toolbar. And the main section of the Support screen is divided into two sections. The narrow column on the left is the main menu; select one subject from the main menu to display the corresponding function screen on the right.

		Support		
				1
My Account	Personal Info	Update Info S	ervice Info	
	User information			
Training	Autel ID:			
Data Logging	Real name:			
	Country/District:	CHINA		
FAQ	Town/City:	BEIJING		
	Company/Institute:			
	Address:			
	Post code:			
	Device information			
	Product serial number:			
	Registration time:	12/12/2021		
	Expired time:	12/03/2105		
	Warranty period:	08/12/2021 - 12/01	2022	

Figure 14-1 Support Application Screen

## 14.2 My Account

The My Account screen displays the comprehensive information of the user and the product, which is synchronized with the online registered account, including Personal Information, Update Information, and Service Information.

## 14.2.1 Personal Information

The User Information and Device Information are both included under the Personal Information section.

- User Information displays detailed information of your registered online Autel account, such as your Autel ID, name, address, and other contact information.
- Device Information displays the registered product information, including the product serial number, registration time, expired time, and warranty period.

## 14.2.2 Update Information

The Update Information section displays a detailed list of the product's software update history, including the product serial number, software version or name, and the update time.

## 14.2.3 Service Information

The Service Information section displays a detailed record list of the device's service history information. Every time the device has been sent back to Autel for repair, the device's serial number and other information, such as the fault type, changed components, or system reinstallation will be recorded and updated to the associated online product account that will be synchronized to the Service Information section.

## 14.3 Training

The Training section provides quick links to Autel's online video accounts. Select a video channel by language to see all available Autel online tutorial videos on such topics as product usage techniques and vehicle diagnostics practices.

## 14.4 Data Logging

The Data Logging section keeps records of all **Feedback** (submitted), **No feedback** (not submitted but saved) or **History** (up to the latest 20 test records) data loggings on the diagnostic system. The support personnel will receive and process the submitted reports through the Support platform. The solution will be sent back as soon as possible. You may continue to correspond with the Support platform until the issue is resolved.

#### > To make a reply in a Data Logging session

- 1. Tap on the **Feedback** tag to view the list of submitted data loggings.
- 2. Select a specific item to view the latest update of the processing progress.
- 3. Tap on the input field on the bottom of the screen and enter your reply, or tap the **Audio** button to record a voice message, or tap the **Camera** button to take a screenshot.
- 4. Tap **Send** to deliver your message to Autel Support.

## 14.5 FAQ

The FAQ section provides comprehensive references for all questions frequently asked and answered about the use of Autel's online member account and shopping and payment procedures.

- Account displays questions and answers about the use of Autel's online user account.
- Shopping displays questions and answers about online product purchase methods or procedures.
- Payment displays questions and answers about online product payment methods or procedures.

## **15** MaxiViewer

The MaxiViewer application allows you to search the functions supported by our tools and the version information. There are two ways for searching, either by searching the tool and the vehicle or searching the functions.

#### > To search by the vehicle

- 1. Tap the **MaxiViewer** application on the MaxiSys Job Menu. The MaxiViewer application screen displays.
- 2. Tap the tool name on the top-left corner to drop down the tool list. Tap the one you want to search.

			MaxiViewer			۹	<b>:</b> 0
8.0	eriya Ultra 🔺 🖪 BMW/1	Series/Year					
	choose brand		choose model		choose year		
# A B C	Baojun	>	All	>	All		
DEFG	Bentley	>		>			
9 H H J K	BMW	•	2 Series	>			
M	Borgward	>	3 Series	>			
O P Q R	Bugatti	>	4 Series	>			
R S T U V	Buick	>	5 Series	>			
W X Y Z	BYD	>	6 Series	>			

3. Tap the vehicle brand, model, and year you want to search.

Figure 15-1 MaxiViewer Screen 1

4. All the functions supported by the selected tool for the selected vehicle display as several columns.

(			MaxiViewe	er		Q, 10
Mattigat	BMW/1	Series/Year		System	Engine     Mo	delSer 🔺
Year	System	Engine	Chassis	Function	Sub function	Version
/	Body	B37	F20	Service	<ul> <li>Newly address the air distribution flap</li> </ul>	Above BM W_V12.00
/	Body	B37	F21	Service	<ul> <li>Newly address the air distribution flap</li> </ul>	Above BM W_V12.00
/	Body	B38	F52	Service	- Newly address the air distribution flap	Above BM W_V12.00
/	Body	B47	F20	Service	- Newly address the air distribution flap	Above BM W_V12.00
/	Body	B47	F21	Service	<ul> <li>Newly address the air distribution flap</li> </ul>	Above BM W_V12.00
/	Body	B58	F20	Service	- Newly address the air distribution flap	Above BM W_V12.00
/	Body	B58	F21	Service	<ul> <li>Newly address the air distribution flap</li> </ul>	Above BM W_V12.00

#### Figure 15-2 MaxiViewer Screen 2

#### > To search by the functions

- 1. Tap the **MaxiViewer** application on the MaxiSys Job Menu. The MaxiViewer application screen displays.
- 2. Tap the tool name on the top-left corner to drop down the tool list. Tap the one you want to search.
- 3. Enter the function you want to search in the top-right search box. The screen will display all vehicles that support this function, along with information such as the vehicles' year, system, function, sub-function, and version.

Cancel		functions	Q ECU	Information		•	Ē
Manilys II	in A B	MW/Model/Year	.]		System 🔺	Engine Mod	lelSer 🔺
Model	Year	System	Engine	Chassis	Function	Sub function	Version
1 Series	/	EPS (Electric Power Steering)	/	E81	ECU infor mation	1	Above BMW_V1 2.00
1 Series	/	EPS (Electric Power Steering)	/	E82	ECU infor mation	/	Above BMW_V1 2.00
1 Series	/	EPS (Electric Power Steering)	/	E87	ECU infor mation	1	Above BMW_V1 2.00
1 Series	/	EPS (Electric Power Steering)	1	E88	ECU infor mation	1	Above BMW_V1 2.00
1 Series	/	EPS (Electric Power Steering)	1	F20	ECU infor mation	1	Above BMW_V1 2.00
1 Series	/	EPS (Electric Power Steering)	/	F21	ECU infor mation	1	Above BMW_V1 2.00
1 Series	/	EPS (Electric Power Steering)	/	F52	ECU infor mation	1	Above BMW_V1 2.00

Figure 15-3 MaxiViewer Screen 3

## 

Fuzzy search is supported. Type in some part of the function-related keywords to find all the available information.

## 16 MaxiVideo

The MaxiVideo application configures the MaxiSys tablet to operate as a digital video scope by simply connecting the tablet to a MaxiVideo Digital Inspection Camera. This function allows you to examine difficult-to-reach areas normally hidden from sight, with the ability to record digital still images and videos, which offers you an economical solution to inspect machinery, facilities, and infrastructure in a safe and quick way.

## 

- 1. The MaxiVideo Digital Inspection Camera and its fittings are additional accessories, and need to be purchased separately. Both sizes (8.5 mm and 5.5 mm) of the imager head are optional and available for purchase.
- This function is compatible with the MaxiVideo Digital Inspection Camera in models MV105S, MV108S, MV105, and MV108.
- Connect the tablet with MaxiVideo Digital Inspection Camera using the USB cable. For detailed operation instructions, please refer to the Quick Reference Guide for the MaxiVideo Digital Inspection Camera.

## 17 Quick Link

The Quick Link application provides you with convenient access to Autel's official website and many other well-known sites in automotive service industry to provide technical help, knowledge bases, forums, and training and expertise consultations.

	Quick	Link	+ =
AUTEL	ALLDATA	OBD WIKI	HAYNESPRO
AUTEL	ALLDATA	OBD wiki	HaynesPro
IDENTIFIX	MITCHELL1	NASTF	TST
IDENTIFIX	Mitchell1	NASTF	TST
AUTODATA	ETI	IATN	
autodata	eti	iATN	

Figure 17-1 Quick Link Screen

### > To open a quick link

- 1. Tap **Quick Link** on the MaxiSys Job Menu. The Quick Link application screen displays.
- 2. Select a website thumbnail from the main section. The Chrome browser is launched and the selected website is opened.

#### > To manage the quick links

- 1. Tap **Quick Link** on the MaxiSys Job Menu. The Quick Link application screen displays.

# **18** Remote Desktop

The Remote Desktop application launches the TeamViewer Quick Support program, which is a simple, fast and secure remote-control interface. You can use the application to receive ad-hoc remote support from Autel's support center, colleagues, or friends, by allowing them to control your MaxiSys tablet on their PC via the TeamViewer software.

## **18.1 Operations**

If you think of a TeamViewer connection as a phone call, the TeamViewer ID would be the phone number under which all TeamViewer Clients can be reached separately. Computers and mobile devices that run TeamViewer are identified by a globally unique ID. The first time the Remote Desktop application is started, this ID is generated automatically based on the hardware characteristics and will not change.

Make sure the tablet is connected to the Internet before launching the Remote Desktop application, so that the tablet is able to receive remote support from the third party.

TeamViewer QuickSupport	i.
How to connect to this device $\leftrightarrow \sigma  transverse con On any other device, go to https://start.teamviewer.com$	Your ID SENO MY ID.
Ready to connect (secure connection)	

Figure 18-1 Remote Desktop Screen

#### > To receive remote support from a partner

- 1. Power on the tablet.
- 2. Tap the **Remote Desktop** application on the MaxiSys Job Menu. The TeamViewer interface displays and the device ID is generated and shown.
- 3. Your partner must install the Remote Control software to his/her computer by downloading the TeamViewer full version program online (<u>http://www.teamviewer.com</u>), and then launch the software.
- 4. Provide your ID to the partner, and wait for him/her to send you a remote-control request.
- 5. A message will appear asking for your confirmation to allow remote-control on your device.
- 6. Tap Allow to accept, or tap Deny to reject.

Refer to the associated TeamViewer documents for additional information.

## **19** User Feedback

The User Feedback application allows you to submit questions related to this product.

- > To send user feedback
  - 1. Tap **User Feedback** on the MaxiSys Job Menu. The device information is automatically synchronized.

- User	feedback
	1 KERCODDODER#
* Serial number Maphabon	10189
* Telephone/Email	
* Feedback type	re Problem 🚫 Software Problem ation Suggestion 🔵 Other
* Theme Touch Scre	en Problem 🔍
* Problem description	
	C B4 E Inter Nation State Load Take
	Submit

Figure 19-1 User Feedback Screen

- Set Telephone/Email, Feedback type, Theme, and Problem description. You can also attach voice recordings, photos, screenshots, images or PDF files. To resolve your issue more efficiently, we recommend you to complete the information as many details as possible.
- 3. Tap **Submit** to send the completed information to Autel's online service center. The submitted feedback will be carefully read and handled by our service personnel.

## **20** Autel User Center

Software updates are available for free for the first year from the date of purchase. The Autel User Center application allows you to register your tool to download the latest released software, thereby enhancing the functionality of the MaxiSys application by adding new vehicle models or enhanced applications to the database.

There are two ways for product registration:

- A. Via the MaxiSys tablet
- > To log in with your account and register your Autel tool
  - 1. Tap **Autel User Center** from the MaxiSys Job Menu. The following screen displays.

≣L
*
Forgot Password
Register

Figure 20-1 Autel User Center Screen

- If you already have an Autel ID, you can log in with your phone number and verification code, or tap Log In with Password to log in with your Autel ID and password. If you don't have an Autel ID yet, tap Register to create an Autel ID.
- 3. Once your account is successfully registered, you will enter the main menu of the Autel User Center.
- 4. Select **Device Management** on the main menu.
- 5. Tap the **Link Device** button on the upper-right corner of the Device Management screen. The serial number and password of the device will automatically appear on the Link Device screen.

6. Tap the **Link** button to complete the product registration.

#### B. Via the Autel website

### > To register your Autel tool

- 1. Visit the website: pro.autel.com.
- 2. If you have an Autel account, sign in with your account ID and password and skip to step 7.
- 3. If you are a new member to Autel, click the **Register** button to create your Autel ID.
- 4. Enter the required personal information in the input fields.
- 5. Enter your email address, then click **Request**. You will receive an email from Autel with your verification code. Open the email and copy the code into the proper input box.
- Set a password for your account, and enter the password again to confirm. Read the Autel User Service Agreement and Autel Privacy Policy, then check the box to accept the terms. After all the information is entered, click Register. A Product Registration screen will appear.
- Your product serial number and password are required to complete your registration. To find your serial number and password on the tool: go to Settings > About.
- 8. Enter your tool's serial number and password on the Product Registration screen. Enter the CAPTCHA code and click **Submit** to complete your registration procedure.

# 21 Maintenance and Service

To ensure that the tablet and the combined VCI unit perform at their optimum level, we advise that the product maintenance instructions covered in this section are strictly followed.

## **21.1 Maintenance Instructions**

The following includes how to maintain your devices, together with precautions to take.

- Use a soft cloth and alcohol or a mild window cleaner to clean the touchscreen of the tablet.
- Do not use any abrasive cleansers, detergent, or automotive chemicals to the tablet.
- Keep the devices in dry conditions and within specified operating temperatures.
- Dry your hands before using the tablet. The touch screen of the tablet may not work if the touch screen is moist, or if you tap the touch screen with wet hands.
- Do not store the devices in humid, dusty or dirty areas.
- Check the housing, wiring, and connectors for dirt and damage before and after each use.
- Check the housing, wiring, and connectors for dirt and damage before and after each use.
- Do not attempt to disassemble your tablet or the VCI unit.
- Do not drop or cause severe impact to the devices.
- Use only authorized battery chargers and accessories. Any malfunction or damage caused by the use of unauthorized battery charger and accessories will void the limited product warranty.
- Ensure that the battery charger does not come in contact with conductive objects.
- Do not use the tablet beside microwave ovens, cordless phones and some medical or scientific instruments to prevent signal interference.

## 21.2 Troubleshooting Checklist

- A. When the tablet does not work properly:
  - Make sure the tablet has been registered online.
  - Make sure the system software and diagnostic application software are properly updated.
  - Make sure the tablet is connected to the Internet.
  - Check all cables, connections, and indicators to see if the signal is being received.
- B. When battery life is shorter than usual:
  - This may happen when you are in an area with low signal strength. Turn off your device if is not in use.
- C. When you cannot turn on the tablet:
  - Make sure the tablet is connected to a power source or the battery is charged.
- D. When you are unable to charge the tablet:
  - Your charger maybe out of order. Contact your nearest dealer.
  - You may be attempting to use the device in an overly hot/cold temperature. Charge the device in a cooler or warmer area.
  - Your device may have not been connected to the charger properly. Check the connector.

### NOTE

If the problems persist, please contact Autel's technical support personnel or your local selling agent.

## 21.3 About Battery Usage

Your tablet is powered by a built-in lithium-ion polymer battery, which enables you to recharge your battery when there is electricity left.

## 

The built-in Lithium-ion Polymer battery is factory replaceable only; incorrect replacement or tampering with the battery pack may cause an explosion.

- Do not use a damaged battery charger.
- Do not disassemble, open, crush, bend, deform, puncture, or shred the battery.
- Do not modify, remanufacture or attempt to insert foreign objects into the battery, or expose the battery to fire, explosion, or other hazards.
- Only use the specified charger and USB cables. Use of non-Autel-authorized charger or USB cables may lead to device malfunction or failure.
- Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazards.
- Avoid dropping the tablet. If the tablet is dropped, especially on a hard surface, and you suspect damage, take the tablet to a service center for inspection.
- Try to keep closer to your wireless router to reduce battery usage.
- The time needed to recharge the battery varies depending on the remaining battery capacity.
- Battery life inevitably shortens over time.
- Unplug the charger once the tablet is fully charged since overcharging may shorten battery life.
- Keep the battery in temperate environments. Do not place it inside a car when it is too hot or too cold, which may reduce the capacity and life of the battery.

## 21.4 Service Procedures

This section provides information on technical support, repair service, and application for replacement or optional parts.

## 21.4.1 Technical Support

If you have any question or problem on the operation of the product, please contact us.

## Autel China Headquarters

- Phone: +86 (0755) 8614-7779 (Monday-Friday, 9AM-6PM Beijing Time)
- Email: <u>support@autel.com</u>
- Address: Floor 2, Caihong Keji Building, 36 Hi-tech North Six Road, Songpingshan Community, Xili Sub-district, Nanshan District, Shenzhen City, China
- Web: <u>www.autel.com</u>

#### **Autel North America**

- Phone: 1-855-288-3587 (Monday-Friday, 9AM-6PM Eastern Time)
- Email: <u>ussupport@autel.com</u>
- Address: 36 Harbor Park Drive, Port Washington, New York, USA 11050
- Web: <u>www.autel.com/us</u>

#### Autel Europe

- Phone: +49(0)89 540299608 (Monday-Friday, 9AM-6PM Berlin Time)
- Email: support.eu@autel.com
- Address: Landsberger Str. 408, 81241 München, Germany
- Web: <u>www.autel.eu</u>

#### Autel APAC

#### Japan:

- Phone: +81-045-548-6282
- Email: <u>support.jp@autel.com</u>
- Address: 6th Floor, Ari-nadoribiru 3-7-7, Shinyokohama, Kohoku-ku, Yokohamashi, Kanagawa-ken, 222-0033 Japan
- Web: <u>www.autel.com/jp</u>

#### Australia:

- Email: ausupport@autel.com
- Address: Unit 5, 25 Veronica Street, Capalaba

#### Autel IMEA

- Phone: +971 585 002709 (in UAE)
- Email: imea-support@autel.com
- Address: 906-17, Preatoni Tower (Cluster L), Jumeirah Lakes Tower, DMCC, Dubai, UAE
- Web: <u>www.autel.com</u>

#### Autel Latin America

#### Mexico:

- Phone: +52 33 1001 7880 (Spanish in Mexico)
- Email: <u>latsupport@autel.com</u>

• Address: Avenida Americas 1905, 6B, Colonia Aldrete, Guadalajara, Jalisco, Mexico

#### Brazil:

- Email: <u>brsupport@autel.com</u>
- Address: Avenida José de Souza Campos nº 900, sala 32 Nova Campinas Campinas – SP, Brazil
- Web: <u>www.autel.com/br</u>

## 21.4.2 Repair Service

If it becomes necessary to return your device for repair, please download the repair service form from <u>www.autel.com</u>, and fill in the form. The following information must be included:

- Contact name
- Return address
- Telephone number
- Product name
- Complete description of the problem
- Proof-of-purchase for warranty repairs
- Preferred method of payment for non-warranty repairs

## NOTE

For non-warranty repairs, payment can be made with Visa, Master Card, or with approved credit terms.

#### Send the device to your local agent, or to the address below:

Floor 2, Caihong Keji Building, 36 Hi-tech North Six Road, Songpingshan Community, Xili Sub-district, Nanshan District, Shenzhen City, China

## 21.4.3 Other Services

You can purchase the optional accessories directly from Autel's authorized tool suppliers, and/or your local distributor or agent.

Your purchase order should include the following information:

- Contact information
- Product or part name
- Item description
- Purchase quantity

## **22** Compliance Information

#### FCC Compliance

#### FCC ID: WQ8-MS909DV2125

This equipment has been tested and verified to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### SAR

The radiated output power of this device is below the FCC radio frequency exposure limits. Nevertheless, the device should be used in such a manner that the potential for human contact is minimized during normal operation.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/Kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels to use only the power required to

reach the network. To avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to antenna should be minimized.

## 23 Warranty

## **12-Month Limited Warranty**

Autel Intelligent Technology Corp., Ltd. (the Company) warrants to the original retail purchaser of this MaxiSys Diagnostic tablet that should this product or any part thereof during normal usage and under normal conditions be proven defective in material or workmanship that results in product failure within twelve (12) months period from the date of purchase, such defect(s) will be repaired, or replaced (with new or rebuilt parts) with Proof of Purchase, at the Company's option, without charge for parts or labor directly related to the defect(s).

## 

If the warranty period is inconsistent with local laws and regulations, please comply with the relevant local laws and regulations.

The Company shall not be liable for any incidental or consequential damages arising from the use, misuse, or mounting of the device. Some states do not allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you.

## This warranty does not apply to:

- a) Products subjected to abnormal use or conditions, accident, mishandling, neglect, unauthorized alteration, misuse, improper installation or repair or improper storage;
- b) Products whose mechanical serial number or electronic serial number has been removed, altered or defaced;
- c) Damage from exposure to excessive temperatures or extreme environmental conditions;
- d) Damage resulting from connection to, or use of any accessory or other product not approved or authorized by the Company;
- e) Defects in appearance, cosmetic, decorative or structural items such as framing and non-operative parts.
- f) Products damaged from external causes such as fire, dirt, sand, battery leakage, blown fuse, theft or improper usage of any electrical source.

## IMPORTANT

All contents of the product may be deleted during the process of repair. You should create a back-up copy of any contents of your product before delivering the product for warranty service.



V2.3 | 2025.04