

Thank you for purchasing this AUTEL tire tread & brake disc laser examiner. Our tool is manufactured to a high standard and will give you years of trouble-free performance when used according to these instructions and properly maintained.



**IMPORTANT:** This tool is a class 3R laser product. Avoid direct eye exposure to the laser. Failure to observe the warning may result in serious injury.

**NOTE:**


- To use the Generate Report and Report Query functions, you need to update the TBE device software to V01.19.00 or later. For update details, see the Quick Reference Guide for the TBE device.
- When updating software, ensure the TBE device is connected to the Internet and that its battery is charged to at least 50 percent or it is connected to a power outlet.

## Generating Report





**IMPORTANT:** Before operating or maintaining this tool, please read the Quick Reference Guide and User Manual for the TBE device carefully, paying extra attention to the safety warnings and precautions. Use this tool correctly and properly. Failure to do so may cause damage and/or personal injury and will void the product warranty.

1



- Refer to the Quick Reference Guide for the TBE device to perform a tire tread check or brake disc check.
- Tap **Data Query** from the Main Menu and tap **Last Test** to view the latest test result.
- Scroll up and tap **Generate Report**. The Generating Report screen appears.



2



- Select or enter the vehicle information to associate the vehicle with the test data and tap **Next** to generate a report.

**Note:** Information marked with red asterisk (\*) is required.



3



- After the report is successfully generated, tap **Check**.
- Use your mobile device to scan the QR code and download the report.

## Querying Report

1



- Tap **Data Query** from the Main Menu and tap **Report Query** to view report records.
- Reports are divided into **Upload complete** (successful records) and **Upload incomplete** (failed records). A maximum of 10 records of each type can be saved. You can tap a successful record to view its corresponding QR code; tap a failed record to view the original test data, and tap **Regenerate Report** to generate the QR code.