


QUICKSTART GUIDE

Ensure your Wi-Fi network is accessible and has a stable connection.


CONNECTING TO Wi-Fi




- Tap on the lower-right corner of the screen.
- The Quick Settings menu will appear.




- A larger menu with additional options, including Wi-Fi will appear.
- Long press and hold the Wi-Fi icon.




- Make sure the Wi-Fi is turned on.
- Select your local network.
- Enter the network password to connect the Wi-Fi.




- The Wi-Fi icon will appear when connection is established.




- On the Android Home screen, tap Settings.



- Make sure the Wi-Fi is turned on.
- Select your local network.




- Enter the network password to connect the Wi-Fi.



- The Wi-Fi icon will appear when connection is established.


QUICKSTART GUIDE

TOOL REGISTRATION VIA PC




1

- Go to <http://pro.autel.com>.
- Click **Create an Autel ID** on the left side of the screen.
- If you already have an Autel ID, sign in and skip to Step 6.




2

- Set Preferred Language.
- Enter your email address as your Autel ID.
- Click **Get Verification Code**.




3

- An email titled "Verification Code for New User Registration" will be sent to you.
- Access the email and obtain the 6-digit verification code.
- Return to <http://pro.autel.com> to continue registration.




4

- Enter the verification code and all other required information marked with a red asterisk.
- Enter the Captcha code as shown.
- Read the **Autel Terms of Use and Privacy Policy** and select the check box to accept the terms.




5

- Click **Create an Autel ID** at the bottom of the screen.
- The **Registration Complete** screen will appear.
- Click **Sign in now** and log in.




6

- Select **Product Registration** from the menu list.
- The **Product Registration** screen will appear.



7

- To obtain the tablet's serial number and password: Tap the **Settings** icon from the Main Menu and tap **About**.




8

- Enter your tablet's serial number and password.
- Enter the Captcha code as shown.
- Click **Submit** to complete tablet registration.

QUICKSTART GUIDE

TOOL REGISTRATION VIA TABLET



- A dialog box will appear asking you to register your tablet.
 • Tap **Register**.



• A sign-in screen will appear.
 • Create an Autel ID using an accessible email address.




• Obtain the verification code from your email.
 • On the tablet registration screen, enter your email address, password, and verification code obtained.



• The serial number and password fields will be automatically displayed.
 • Tap **REGISTER**.

NOTE: To find your product serial number and register password, go to the Main Menu, and tap **Settings > About**.


DOWNLOAD SOFTWARE UPDATES




• Connect your tablet to Wi-Fi and plug it into a power source.
 • Tap the **Maxisys** application or the **Maxisys Home** icon at the bottom of the screen to open the Main Menu.



• If updates are available, the number of available updates will appear as a badge on the **Update** icon.
 • Tap the **Update** button to view the list of available updates.



• Download the system update by tapping the update button on the right.



• Download any available updates for each vehicle manufacturer you need.
 • Tap the information icon **i** next to each update item to view update details.

NOTE: We recommend you update one at a time. Selecting **Update All** will take more time.

QUICKSTART GUIDE



EXTEND INITIAL YEAR OF COVERAGE WITH

1 YEAR-TCP

TOTAL CARE PROGRAM

PURCHASE TO **EXTEND** MAXISYS
WARRANTY & SOFTWARE
SUBSCRIPTION COVERAGE FOR **ONE YEAR**

DON'T WAIT FOR INITIAL YEAR EXPIRATION

PURCHASE & ACTIVATE A NEW TCP SUBSCRIPTION BEFORE UPDATES EXPIRE TO LIMIT DOWNTIME AND ENSURE CONTINUED VEHICLE COVERAGE

NEW SAME DAY ORDER & ACTIVATION
GET YOUR SUBSCRIPTION FASTER
RECEIVE ACTIVATION CODES VIA EMAIL
ASK YOUR LOCAL TOOL DEALER





REGISTER YOUR MAXISYS AT
PRO.AUTEL.COM & PURCHASE TCP

USE ACTIVATION CODE ON CARD OR
DIGITAL CODE PROVIDED IN EMAIL

REDEEM CODE TO ACTIVATE
SUBSCRIPTION & WARRANTY




YouTube
TRAINING VIDEOS
@AutelTools




View More Autel Videos at: <https://www.youtube.com/auteltools>

PRINTING INSTALLATION & SETUP


Works with any printer with a Wi-Fi connection. No need for special software or driver on the tablet.




- Make sure your Windows PC and tablet are on the same Wi-Fi network.
- On your PC, go to www.autel.com, select **Support > Downloads > Autel Update Tools**.



- Locate the **Maxi PC Suite** software and click the **Download here** button.
- Open the .zip file.



- Double-click the **setup.exe** file to install the application.



- In the **PC Link** dialogue box, check **Auto Print** to automatically use the default printer.
- Click **Quick Print** to use the default printer or click **Print** to choose a printer.

QUICKSTART GUIDE

Ensure your Wi-Fi network is accessible and has a stable connection.

VCI CONNECTION VIA WI-FI



- 1 Tap the **VCI Manager** icon from the Main Menu or from the bottom toolbar.
- 2 Tap **Wi-Fi** from the left side of the screen.



- 3 - Your tablet will automatically start scanning for available VCI devices. Found devices are listed on the right side of the screen.



- 4 - When a connection is established, the status of the connected device will read, "Connected".




- 4 - When the VCI is ready for use, a green badge will appear on the VCI button at the bottom of the screen.

VCI CONNECTION VIA BLUETOOTH




- 1 Tap the **VCI Manager** from the Main Menu or from the bottom toolbar.
- 2 Tap **VCI BT** from the left side of the screen.



- 3 - Your tablet will automatically start scanning for available VCI devices. Found devices are listed on the right side of the screen.



- 4 - When a connection is established, the status of the connected device will read, "Connected".



- 4 - When the VCI device is ready for use, a green badge will appear on the VCI button at the bottom of the screen.


QUICKSTART GUIDE

Ensure your Wi-Fi network is accessible and has a stable connection.


VCI SOFTWARE UPDATES



- 1
- Connect the VCI device to the MaxiSys tablet via USB.
 - Connect the VCI to a power source to ensure updates are installed correctly.



- 2
- Tap the **VCI Manager** application from the Main Menu.



- 3
- Tap **VCI Update** from the left side of the screen.



- 4
- The current and latest version of the VCI software will appear.
 - If available, tap the **Update now** button to download any software updates.


VID — VEHICLE IDENTIFICATION DETECTION | SCAN VIN




- 1
- Tap **Diagnostics** from the Main Menu.



- 2
- Tap the blue **VID** button on the top left of the screen.
 - Tap **Scan VIN License** from the drop-down menu.



- 3
- Position the camera so the VIN (located on the vehicle dash or vehicle door jamb) appears within the scanning frame.




- 4
- The VIN is scanned and recognized automatically.
 - The result will appear in the Recognition result dialog box.
 - Tap **OK** to confirm the VIN.

QUICKSTART GUIDE

VID — VEHICLE IDENTIFICATION DETECTION AUTO VIN DETECT (COMPATIBLE WITH VEHICLES 2007 AND NEWER)



1 • Tap **Diagnostics** from the Main Menu.



2 • Tap the blue **VID** button on the top left of the screen.



3 • Select **Auto detect** from the drop-down menu.




4 - Once the vehicle is successfully identified, the *Diagnostics Menu* will appear.


AUTO-SCAN




1 • Tap **Diagnostics** from the Main Menu.



2 • Select the vehicle manufacturer.



3 • Select **Automatic Selection** to acquire VIN automatically. Tap **Manual input** to type in the VIN.



4 - All available systems will appear.

QUICKSTART GUIDE

TOPOLOGY MODULE MAPPING

• Please note: Not all vehicles support topology mapping of all vehicle systems.




1 • Tap **Diagnostics** from the Main Menu.



2 - A topology module map of all available systems will display after the Auto SCAN. All systems display in Dark Blue.
 • Tap **Fault scan** at the bottom of the screen to scan system faults.




3 - A system found to have faults will appear in orange, with the number of faults detected shown on the upper-right corner of the system icon.
 - A green system icon indicates the system is without faults; A gray system icon indicates the system did not respond when scan was attempted.



4 • Tap the **List** tab to view all available systems in list format.
 - The third column indicates the scanning status.
 • Tap **Fault scan** at the bottom of the screen to scan system for faults.



5 - Data Trouble Codes (DTCs) can be viewed directly after scanning.
 - Fault | #: Indicates faults are present; “#” indicates the number of detected faults.
 - Pass | No Fault: Indicates the system was scanned and no fault was detected.
 - No Response: Indicates the system was unresponsive.



6 - For vehicles that do not support topology mapping, a System List will appear after the Auto SCAN.
 • Tap **Fault scan** at the bottom of the screen to scan system for faults.
 • DTCs can be viewed after scanning. Scroll to review systems.


QUICKSTART GUIDE

PRE/POST SCAN REPORTS


Prior to Running Pre/Post Scans, we recommend you take the following steps to customize your reports.




- Tap **Data Manager** from the Main Menu.



- Tap the **Workshop Information** application.




- Complete the fields on this screen by tapping on each field and entering information. The information entered here will appear on every Pre- and Post-Scan report generated.




- To add a logo: Tap the image icon and select from the drop-down menu to either take a photo with the tablet or upload an image.



- The generated Pre- and Post-Scan reports are now complete with shop information and ready to be emailed to an insurance company or printed for the customer.



- Reports are stored in Vehicle History, accessible through Data Manager or through **Diagnostics > History**.



- Access stored reports.




- Select the pencil icon from the drop-down menu, choose View PDF, Print, E-mail or Delete.

QUICKSTART GUIDE

Ensure your Wi-Fi network is accessible and has a stable connection.

MAXISYS SYSTEM SUITE APPS


SERVICE



SERVICE

Provides quick access to the vehicle systems for various service and maintenance tasks. Comprehensive service functions, including Oil Reset, EPB, SAS, DPF, TPMS, and BMS.


BATTERY TEST



BATTERY TEST

Conducts battery and cranking/charging systems analysis and enables technicians to view the health status of vehicle's battery and electrical system. Functions include in-vehicle test and out-vehicle test.

MULTIMETER



MULTIMETER


Serves as a multi-function, multi-range measuring instrument. This tool performs AC/DC voltage, AC/DC current, resistance, diode, and connectivity tests, and the test results are displayed in various formats for easy viewing.

QUICKSTART GUIDE

Ensure your Wi-Fi network is accessible and has a stable connection.

MAXISYS SYSTEM SUITE APPS


DATA LOGGING



DATA LOGGING

Interactive recording sessions save vehicle testing data and enable direct contact with Autel technical support staff for first-hand troubleshooting of diagnostic bugs and errors.


REMOTE DESKTOP



REMOTE DESKTOP

Enables you to authorize our tech-support specialists to remotely log into the tablet and help you update software on the tablet and VCI, and perform difficult diagnostic procedures or complicated vehicle services. This real-time support provides quick and accurate solutions.

DATA MANAGER



DATA MANAGER

Designed to store all data files, including customer information, vehicle ID, and vehicle diagnostic records.